


Operating instructions



for Washing machine W 3164 WSS Edition 111

To avoid the risk of accidents or damage to the machine it is **essential** to read these instructions before it is installed and used for the first time.

en - GB

M.-Nr. 09 527 420

Caring for our environment


Disposal of the packing material

The transport and protective packing has been selected from materials which are environmentally friendly for disposal and should be recycled.

Recycling the packaging reduces the use of raw materials in the manufacturing process and also reduces the amount of waste in landfill sites. Ensure that any plastic wrappings, bags etc. are disposed of safely and kept out of the reach of babies and young children. Danger of suffocation!

Disposal of your old machine

Electrical and electronic machines often contain materials which, if handled or disposed of incorrectly, could be potentially hazardous to human health and to the environment. They are, however, essential for the correct functioning of your machine. Please do not therefore dispose of it with your household waste.



Please dispose of it at your local community waste collection / recycling centre or contact your Dealer for advice. Ensure that it presents no danger to children while being stored for disposal.

| | |
|--|----|
| Caring for our environment | 2 |
| Warning and Safety instructions | 6 |
| Operating the washing machine | 13 |
| Control panel | 13 |
| Before using for the first time | 14 |
| Washing environmentally and economically | 15 |
| Energy and water consumption | 15 |
| Detergent | 15 |
| Choosing the correct additional options (Short, Soak, Pre-wash) | 15 |
| When drying with a tumble dryer | 15 |
| How to wash correctly | 16 |
| Extras | 21 |
| Short | 21 |
| Pre-wash | 21 |
| Soak | 21 |
| Water plus | 21 |
| Spinning | 22 |
| Final spin speed | 22 |
| Rinse and interim spin | 22 |
| You can also omit the final spin | 22 |
| Programme chart | 23 |
| Programme sequence | 26 |
| Garment care label symbols | 28 |

Contents

| | |
|---|----|
| Changing the programme sequence | 29 |
| Cancelling a programme | 29 |
| Interrupting a programme | 29 |
| Making changes to a programme | 29 |
| Adding or removing laundry after a programme has started | 30 |
| Detergent | 31 |
| The correct detergent | 31 |
| Water softeners | 33 |
| Washing with several components | 33 |
| Fabric conditioners and liquid starch | 34 |
| Automatic dispensing of fabric conditioner or liquid starch to laundry at the end of a programme | 34 |
| Adding fabric conditioner or starch separately | 34 |
| Colour run and dye removers / dyes | 34 |
| Cleaning and care | 35 |
| External casing and control panel | 35 |
| Extra cleaning | 35 |
| Cleaning the detergent dispenser drawer | 35 |
| Cleaning the water inlet filters | 37 |
| Problem solving guide | 38 |
| The programme does not start | 38 |
| The wash programme stops and a fault indicator light comes on | 39 |
| General problems | 40 |
| An unsatisfactory wash result | 41 |
| The drum door does not open when you press the Door button | 42 |
| Opening the drum door in the event of a blocked drain outlet and/or power failure | 43 |
| Blocked drain outlet | 43 |
| After sales service | 45 |
| Future updates (PC) | 45 |
| Guarantee | 45 |
| Optional spare parts and accessories | 45 |

| | |
|--|----|
| Installation and connection | 46 |
| Front view | 46 |
| Rear view | 47 |
| Installation surface | 48 |
| Installing the washing machine | 48 |
| Removing the transit bars | 48 |
| Re-fitting the transit bars | 50 |
| Levelling the machine | 51 |
| Screwing out and adjusting the feet | 51 |
| Building under a continuous worktop/in a kitchen run | 52 |
| Washer and Dryer stack | 52 |
| The Miele water safety system | 53 |
| Connection to the water supply | 54 |
| Connection to the drainage system | 55 |
| Electrical connection U.K. | 56 |
| | |
| Consumption data | 57 |
| Notes for test institutes: | 57 |
| | |
| Technical data | 58 |
| | |
| Programmable functions | 59 |
| Water plus system | 59 |
| Gentle action | 60 |
| Suds cooling | 61 |
| Memory function | 62 |
| Soak duration | 63 |
| | |
| Optional accessories | 64 |
| CareCollection | 64 |

Warning and Safety instructions

This machine conforms to current safety requirements. Inappropriate use can, however, lead to personal injury and damage to property.

To avoid the risk of accidents and damage to the machine, please read these instructions carefully before using it for the first time. They contain important information on its safety, use and maintenance.

Keep these instructions in a safe place and ensure that new users are familiar with the content. Pass them on to any future owner.

Correct application

- ▶ This washing machine is not designed for commercial use. It is intended for use in domestic households and in similar working and residential environments.
- ▶ The machine is not intended for outdoor use.
- ▶ It must only be used as a domestic appliance to wash items which are specified by the manufacturer as being machine-washable on the wash care label, and textiles composed of hand-washable wool or wool blend fabrics as well as satin, lace, silk and other hand-washable garments. Miele cannot be held liable for damage resulting from incorrect or improper use or operation.
- ▶ The machine can only be used by people with reduced physical, sensory or mental capabilities, or lack of experience or knowledge, if they are supervised whilst using it or have been shown how to use it in a safe way and understand the hazards involved.

Safety with children

- ▶ Children under 8 years of age must be kept away from the machine unless they are constantly supervised.
- ▶ Children 8 years and older may only use the machine unsupervised if they have been shown how to use it in a safe way and recognise and understand the consequences of incorrect operation.
- ▶ Children must not be allowed to clean or maintain the machine unsupervised.
- ▶ Please supervise children in the vicinity of the washing machine and do not let them play with it.
- ▶ For machines with a 'porthole' door, remember that the porthole glass will be hot when washing at high temperatures
Do not let children touch it.

Warning and Safety instructions

Technical safety

▶ Before setting up the washing machine, check it for any externally visible damage.

Do not install or use a damaged machine.

▶ Before connecting the machine, ensure that the connection data on the data plate (fuse rating, voltage and frequency) match the mains electricity supply. If in any doubt, consult a qualified electrician.

▶ The electrical safety of this washing machine can only be guaranteed when correctly earthed. It is most important that this basic safety requirement is observed and regularly tested, and where there is any doubt the household wiring system should be inspected by a qualified electrician. The manufacturer cannot be held liable for the consequences of an inadequate earthing system (e.g. electric shock).

▶ Do not connect the washing machine to the mains electricity supply by an extension lead. Extension leads do not guarantee the required safety of the machine (e.g. fire risk from overheating).

▶ Faulty components must only be replaced by genuine Miele original spare parts. Only when these parts are fitted can Miele guarantee the safety standards of the machine.

▶ Please observe the instructions in "Installation and connection" and "Technical data".

▶ The electrical socket should be easily accessible after installation so that the machine can be disconnected from the electricity supply when necessary.

Warning and Safety instructions

- ▶ Unauthorised repairs could result in unforeseen dangers for the user, for which Miele cannot accept liability. Repairs should only be undertaken by a Miele approved service technician, otherwise any subsequent damage will not be covered by the guarantee.
- ▶ If the electrical connection cable is faulty it must only be replaced by a Miele approved service technician to protect the user from danger.
- ▶ The machine must be isolated from the electricity supply when cleaning and maintaining the machine and in the event of a fault.
- ▶ This machine must only be connected to the on-site water supply using a new hose kit. Old hoses must not be re-used.
- ▶ This machine must not be used in a non-stationary location (e.g. on a ship).
- ▶ Do not make any alterations to the machine, unless authorised to do so by Miele.
- ▶ In areas which may be subject to infestation by cockroaches or other vermin, pay particular attention to keeping the machine and its surroundings clean at all times. Any damage caused by cockroaches or other vermin will not be covered by the guarantee.

Warning and Safety instructions

Correct use

- ▶ The maximum load of dry laundry for this machine is 7 kg. See the "Programme chart" for the maximum recommended loads in individual programmes.
- ▶ Do not install your washing machine in rooms where temperatures below freezing may occur. Frozen hoses may burst or split. The reliability of the electronic control unit may be impaired at temperatures below freezing point.
- ▶ Before using the machine for the first time, check that the transit bars at the rear of the machine have been removed (see "Installation and connection - Removing the transit bars"). During spinning, a transit bar which is still in place may result in damage to both the machine and adjacent furniture or appliances.
- ▶ Turn off the stopcock if the machine is to be left for any length of time (e.g. holiday), especially if there is no floor drain (gully) in the immediate vicinity.
- ▶ Flooding danger.
If hooking the drain hose into a wash basin, check that the water can drain off quickly enough to prevent the sink from overflowing. Make sure that the drain hose is secure, so that the force of the water flowing out of the hose does not dislodge it.
- ▶ Take care to ensure that foreign objects (e.g. nails, pins, coins, paper clips) do not find their way into the machine with the laundry. These may damage components of the machine (e.g. suds container, drum), which in turn can result in damage to the laundry.

Warning and Safety instructions

- ▶ If the correct amount of detergent is dispensed, the machine should not need to be descaled. If, however, you do wish to descale it, only use proprietary non-corrosive descaling agents and strictly observe the instructions on the packaging. A special descaling agent is available to order from Miele (see "Optional accessories").
- ▶ Textiles which have been pre-treated in solvent based cleaning agents must be thoroughly rinsed in clean water before being washed in the machine.
- ▶ Do not use solvent based cleaning agents, e.g. those containing benzene, in this machine, as this may result in damage to component parts and create toxic fumes. Such agents also pose a fire and explosion hazard.
- ▶ Do not use solvent based cleaning agents, e.g. those containing benzene to clean the outside surfaces of this machine. They can cause damage to plastic surfaces.
- ▶ Only use dyes specified by the manufacturer as being suitable for use in a domestic washing machine. Always observe the manufacturer's instructions carefully.
- ▶ Colour run and dye removers contain sulphur compounds which can cause damage such as corrosion. Do not use these products in this machine.
- ▶ If detergent comes into contact with the eyes, rinse them thoroughly with lukewarm water immediately. If swallowed, seek medical assistance immediately and retain the packaging or label for reference. Those with skin problems or sensitive skin should avoid their skin coming into contact with detergent.


Warning and Safety instructions

Accessories

- ▶ Accessory parts may only be fitted when expressly approved by Miele. If other parts are used, guarantee, performance and product liability claims will be invalidated.
- ▶ A Miele tumble dryer can be stacked on top of a Miele washing machine using the appropriate stacking kit (available as an optional accessory).
- ▶ If installing the machine on a Miele plinth, (available as an optional accessory, depending on country), please make sure you order the right one for this washing machine.

Miele cannot be held liable for damage caused by non-compliance with these Warning and Safety instructions.

Control panel



① Display

The display shows the programme duration (time left).

② Start button

Starts the wash programme.

③ Additional option buttons

Additional options can be added to the basic programme.

Use the top button to select either *Soak*, *Pre-wash*, or *Short*.


Use the lower button to select the *Water plus* option.

Indicator light on = option selected

Indicator light off = option not selected

④ Spin button with spin speed

indicator lights

For selecting the spin speed or  (Without spin).

⑤ Programme selector

For selecting the wash programme and temperature for that programme. The programme selector can be turned clockwise or anti-clockwise.

⑥ Fault indicator light

⑦ button

For switching the machine on or off or interrupting a programme.

⑧ Door button

Opens the machine door.

Before using for the first time



Before using the machine for the first time, ensure that it is correctly installed and connected. See "Installation and connection". Also check that the drain filter is securely tightened to prevent the risk of water leaks during use.

This washing machine has undergone a complete functional test at the factory and there will be some residual water in the drum from this process.

For safety reasons, spinning is not possible until the machine has been prepared for using for the first time. To activate the spinning function you must run a wash programme without laundry and without detergent.

Using detergent could result in an excessive build-up of foam.

This also activates the ball valve. The ball valve prevents detergent escaping from the suds container into the sump during a wash programme, thus making maximum use of the detergent.

- Open the stopcock.
- Press the  button in.
- Turn the programme selector to *Cottons* .
- Press the *Start* button.

When the programme has finished, your machine is ready to use for the first time.

Washing environmentally and economically

Energy and water consumption

- Water consumption and energy usage are determined by the size of the load.
To make the most out of your machine, load the maximum dry load for the programme you are using.
- When smaller amounts of laundry are washed, the automatic load recognition system will reduce the amount of water, time and energy used. This may mean that the time left shown in the display is adjusted during the course of the wash programme.
- Use the *Express 20* programme for small loads.
- Modern detergents make it possible to wash at lower temperatures (e.g. 20°C). Washing using lower temperature settings will save energy.
- Use the *Soak* additional option instead of *Pre-wash*. If *Soak* is followed immediately by a main wash, the same suds are used.

Detergent

- Do not exceed the amounts of detergent recommended by the manufacturer on the packaging.
- Reduce the amount of detergent with smaller loads (approx. $\frac{1}{3}$ less than the amount recommended can be used when washing a half load).

Choosing the correct additional options (Short, Soak, Pre-wash)

Select:

- A wash programme together with the *Short* option for light to normal soiling where there are no obvious marks.
- A wash programme without any additional options for normal to heavy soiling with visible staining.
- A wash programme together with the *Soak* option for heavily soiled laundry.
- The *Pre-wash* additional option for laundry with large amounts of dirt (e.g. dust, sand).

When drying with a tumble dryer


Selecting the highest possible spin speed for the wash programme will save energy when drying in a tumble dryer afterwards.

How to wash correctly

Brief instructions

The headings numbered ①, ②, ③, . . . show the operating sequence and can be used as brief instructions.

① Sort the laundry



- Empty all pockets.

⚠ Foreign objects (e.g. nails, coins, paper clips, etc.) can cause damage to garments and components in the machine.

- Badly soiled areas, stains etc. should be cleaned as soon as possible, preferably whilst still fresh. Spillages should be carefully dabbed off using a soft colourfast cloth. Do not rub!

Badly soiled areas can be pre-treated with liquid detergent, stain removers etc. first, following the manufacturer's instructions. With particularly stubborn stains ask your cleaner for advice.

⚠ If you use a solvent-based cleaning agent (e.g. one containing benzene) to pre-treat a stain, make sure that any plastic parts (e.g. buttons) are protected, and that the cleaning agent is rinsed off before washing the garment in the machine.

⚠ Do not use solvent-based cleaning agents in or on this machine.

- Sort the laundry by colour and by care label. Most garments have a textile care label in the collar or side seam.

Dark textiles often contain excess dye and should be washed separately several times before being included in a mixed load. Always wash whites and coloureds separately.

- Curtains: Remove lead weights first or place in a laundry bag.
- Underwiring and collar stiffeners: Any loose wiring in bras, shirt collar stiffeners, etc. should be removed or sewn in.
- Turn garments inside out, if recommended by the manufacturer.
- Close any zips, fasten hooks and eyes etc before washing.
- Fasten duvet covers etc. to prevent small items from being rolled up inside them.

Do not wash any items in this machine which are specified by the manufacturer as **not washable** on the care label. (☒ symbol)

How to wash correctly


2 Switch on the washing machine

3 Load the drum

- Press the *Door* button to open the drum door.
- Unfold the laundry and load loosely into the drum. Mixing both large and small items gives better wash results and also helps distribute the load evenly during spinning.


The most efficient use of energy and water is achieved when a full load is washed. However, do not overload as this causes creases and reduces cleaning efficiency.

Make sure that items do not get caught between the drum door and the seal.



- Shut the door with a gentle swing.

4 Select a programme



- Turn the programme selector to the required programme.

The estimated programme duration in hours and minutes will appear in the display.


During the first 10 minutes the washing machine measures how much water is being absorbed by the laundry and uses this to calculate the load. The programme duration may be longer or shorter depending on this absorbency rate.

How to wash correctly

5 Select any additional option(s)

Each press of the top button selects the additional options in the following order: *Soak*, *Pre-wash* or *Short* or no option.

Use the lower button to select the *Water plus* option.




- Select the option(s) you want.

Not all the additional options are suitable for use with every programme.

You can only select additional options which are compatible with the programme being used.

6 Select a spin speed



- Press the Spin button repeatedly until the indicator light for the spin speed you want comes on.

How to wash correctly

7 Add detergent


It is important to dispense the correct amount, because . . .

. . . too little detergent results in:

- Laundry not getting properly clean and with time it may become grey and hard to the touch.
- Greasy particles clinging to the laundry.
- Limescale deposits on the heater elements.



. . . too much results in:

- Excessive foam which causes a low level of agitation and poor wash, rinse and spin results.
- Higher water consumption (an additional rinse cycle will automatically switch in).
- A burden to the environment.



- Pull out the detergent drawer and place detergent in the compartments as follows:



Detergent for the pre-wash (divide the total recommended amount as follows: add $\frac{1}{3}$ to compartment  and $\frac{2}{3}$ to compartment .



Detergent for the main wash, including Soak if selected



Fabric conditioner or liquid starch

- Close the detergent drawer.

See "Detergent" for further information.

How to wash correctly

8 Start the programme


- Press the flashing *Start* button.


9 Unload the drum

U will appear in the display at the end of the programme.

- Press the *Door* button to open the drum door.
- Remove the laundry.

Check that all items have been removed from the drum. Items left in the drum could discolour other items in the next wash or become discoloured themselves.



- Check the folds in the door seal for any small articles, e.g. buttons, which might be lodged there.
- Press the  button to release it and turn the programme selector to *Finish*.
- Close the drum door. Otherwise there is the danger of objects being placed inadvertently in the drum. If these remained unnoticed and were washed in the next load, they could damage the laundry.

You can use the extra option buttons to augment the wash programmes.

Short

For light to normal soiling with no visible staining.

This shortens the programme running time.

Pre-wash

For laundry with large amounts of dirt e.g. dust, sand.

Soak

For heavily soiled and stained items with protein stains (e.g. blood, fats and oils, cocoa).

- A length of time of between 30 minutes and 2 hours can be programmed in 30 minute increments for the soak process.
- The default setting is 2 hours.

To programme in a different soak period see "Programmable functions – Soak".

Water plus

The water level in the main wash and the rinses will be increased.

You can select other settings for *Water plus*. These are described in "Programmable functions".



The following extra options can be selected in addition to the programme:

Only one of the following can be selected at a time: *Short*, *Pre-wash* or *Soak*.

| | Short | Pre-wash | Soak | Water plus |
|---------------------------|-------|----------|------|------------|
| Cottons | X | X | X | X |
| Minimum iron | X | X | X | X |
| Delicates | X | X | X | – |
| Automatic | – | – | – | – |
| Dark garments | X | X | X | – |
| Shirts | – | X | X | – |
| Denim | X | X | X | – |
| Express | – | – | – | X |
| Silks (👚) | – | – | – | – |
| Woolens (👚) | – | – | – | – |
| Drain/Spin | – | – | – | – |
| Separate rinse/ Starch | | | | X |

Spinning

Final spin speed

| Programme | rpm |
|---|------|
| Cottons | 1400 |
| Minimum iron | 1200 |
| Delicates | 400 |
| Automatic | 1200 |
| Dark garments | 1200 |
| Shirts | 600 |
| Denim | 900 |
| Express | 1400 |
| Silks  | 600 |
| Woolens  | 1200 |
| Drain/Spin | 1400 |
| Separate rinse/Starch | 1200 |

You can reduce the final spin speed. However, you cannot select a final spin speed higher than that shown in the chart above.


Please note:

For programmes with a maximum spin speed not shown on the control panel, the nearest spin speed above it will light up. However, to protect the laundry the machine will only spin at the spin speed quoted in the chart.

Rinse and interim spin

There is a spin after the main wash and between the rinses. A reduction in the final spin speed will also reduce the interim spin speed. If a spin speed of less than 700 rpm is selected for a *Cottons* programme, an additional rinse is introduced.



You can also omit the final spin

- Press the Spin button repeatedly until the  indicator light comes on. The laundry is not spun after the final rinse. The water will drain away and the machine will go straight into the anti-crease stage. With some programmes an additional rinse is introduced if this setting is selected.



Programme chart

| Cottons | | 90°C / 30°C | Max. load 7.0 kg |
|---|--|---------------------|-------------------------|
| Use for | Cotton, linen or cotton mix fabric, e.g. table linen, towelling, underwear, T-shirts etc. | | |
| Note | Where particularly high levels of hygiene are required please select 90°C. | | |
| Cottons | | 60°C/40°C | Max. load 7.0 kg |
| Use for | Normally soiled cotton garments | | |
| Note | <ul style="list-style-type: none"> – These settings are the most efficient in terms of energy and water consumption for washing cottons. – With 60°C the actual wash temperature reached will be lower than 60°C although the wash performance is the same as with a standard Cottons 60°C programme. | | |
| Note for test institutes: | | | |
| Test programme in accordance with EN 60456 and energy label with Directive 1061/2010. | | | |
| Minimum iron | | 30°C to 60°C | Max. load 3.0 kg |
| Use for | Synthetic, mixed fibre and easy care cotton. If fabrics have a high proportion of man-made fibres it is advisable to programme the machine for "Gentle action". See "Programmable functions". | | |
| Note | Reduce the spin speed for fabrics which crease easily. | | |
| Delicates | | 20°C to 40°C | Max. load 2.0 kg |
| Use for | Delicate garments made from synthetic fibre, mixed fibre and rayon. Curtains, including net curtains, specified as machine-washable by the manufacturer. | | |
| Note | <ul style="list-style-type: none"> – Dust in curtains usually makes using a programme with pre-wash advisable. – Deselect the spin for items which crease easily. | | |
























Programme chart

| | | | |
|---|--|---------------------|-------------------------|
| Automatic | | cold to 40°C | Max. load 3.5 kg |
| Use for | Mixed loads of garments suitable for the <i>Cottons</i> and <i>Minimum iron</i> programmes. Sort according to colour. | | |
| Note | The wash parameters (e.g. water level, wash rhythm and spin speed) are adjusted automatically in this programme to ensure the best possible care and wash result for each item. | | |
| Dark garments | | 40°C | Max. load 3.0 kg |
| Use for | Black and dark garments made from cotton or mixed fibre. | | |
| Note | Wash inside out. | | |
| Shirts | | 40°C | Max. load 2.0 kg |
| Notes | <ul style="list-style-type: none"> – Pre-treat collars and cuffs if necessary. – Wash silk garments in the <i>Silks</i>  programme. | | |
| Denim | | 40°C | Max. load 3.0 kg |
| Notes | <ul style="list-style-type: none"> – Wash denim inside out. – Denim often contains excess dye and may run during the first few washes. Wash light and dark coloured items separately. | | |
| Express | | 40°C | Max. load 3.0 kg |
| Use for | Small loads of items which require freshening up and which can be washed in a <i>Cottons</i> programme. | | |
| Silks  | | 30°C | Max. load 1.0 kg |
| Use for | Silks and other handwashable fabrics with no wool content. | | |
| Note | Place tights, bras etc. in a washing bag. | | |

Programme chart


| Woollens  | | cold to 40°C | Max. load 2.0 kg |
|---|---|-------------------------|-------------------------|
| Use for | Machine-washable or hand-washable wool or wool blend fabrics. If the care label does not specify a temperature, wash using the cold setting. | | |
| Note | Reduce the spin speed for items which crease easily. | | |
| Drain / Spin | | | |
| Notes | <ul style="list-style-type: none"> – Drain only: Select <i>No</i>  (No spin). – Make sure you select the appropriate spin speed. | | |
| Separate rinse/Starch | | Max. load 7.0 kg | |
| Use for | <ul style="list-style-type: none"> – Rinsing hand-washed items. – Starching table cloths, serviettes and workwear | | |
| Notes | <ul style="list-style-type: none"> – Reduce the spin speed for fabrics which crease easily. – Items for starching should be freshly laundered but not treated with fabric conditioner. – You can achieve a particularly good rinse result with two rinses by activating the <i>Water plus</i> extra option. For this, option P3 or P4 of the <i>Water plus system</i> programmable function must be activated (see "Programmable functions" at the end of this booklet). | | |

Programme sequence

| | Main wash | | Rinses | | Spinning | |
|---|---|-------------|---|---------------------|--------------|------------|
| | Water level | Wash rhythm | Water level | Rinses | Interim spin | Final spin |
| Cottons |  | Ⓐ |  | 2-4 ¹⁾²⁾ | ✓ | ✓ |
| Minimum iron |  | Ⓒ |  | 2-3 ³⁾ | ✓ | ✓ |
| Delicates |  | Ⓓ |  | 3 | – | ✓ |
| Automatic |  | Ⓐ Ⓑ Ⓒ |  | 2-3 ³⁾ | ✓ | ✓ |
| Dark garments |  | Ⓑ |  | 3-4 ³⁾ | ✓ | ✓ |
| Shirts |  | Ⓒ |  | 2 | – | ✓ |
| Denim |  | Ⓒ |  | 3 | – | ✓ |
| Express |  | Ⓑ |  | 2-3 ³⁾ | ✓ | ✓ |
| Silks  |  | Ⓕ |  | 2 | – | ✓ |
| Woolens  |  | Ⓕ |  | 2 | ✓ | ✓ |
| Drain/Spin | – | – | – | – | – | ✓ |
| Separate rinse/Starch | – | – |  | 1 | – | ✓ |
| Please see next page for description of the symbols | | | | | | |

 = Low water level

 = Medium water level

 = High water level

(A) = Intensive rhythm

(B) = Normal rhythm

(C) = Gentle rhythm

(D) = Sensitive rhythm

(E) = Ultra sensitive rhythm

(F) = Handwash rhythm

This machine has fully electronic controls with automatic load recognition. It takes in the right amount of water required for the programme depending on the amount of laundry and its absorbency rate. This means that programme cycles and durations can vary.

The programme sequences outlined in the chart are based on the basic programme with a full load. Extra options which can be selected have not been taken into account.

Special features in the programme sequences:

Anti-crease:


At the end of the programme, the drum continues to turn at intervals for up to 30 minutes to help prevent creasing.

Exception: There is no anti-crease phase in the *Woolens* programme.

The door can be opened and laundry removed at any time during the anti-crease phase.

1) A second rinse is carried out when a temperature of 60°C or more than 60°C has been selected. A third rinse is carried out when a temperature below 60°C is selected.

2) A third or fourth rinse is carried out if:

- there is too much foam in the drum
- a spin speed lower than 700 rpm has been selected
-  has been selected

3) A third rinse is carried out if:

-  has been selected

Garment care label symbols

| Washing | |
|--|---|
| The figure quoted in the bucket is the maximum temperature the garment can be washed at. The number of bars under the symbol indicates the level of agitation permitted. | |
| | No bar under the symbol: = normal agitation |
| | One bar under the symbol: = reduced agitation |
| | Two bars under the symbol: = much reduced agitation |
| | Hand wash (if no temperature is specified use the lowest temperature or cold) |
| | Do not wash |

Programme selection

| Programme | Garment care label symbols |
|--------------|----------------------------|
| Cottons | |
| Minimum iron | |
| Delicates | |
| Woollens | |
| Silks | |
| Express | |
| Automatic | |

| Drying | |
|---|--------------------|
| The number of dots indicates the drying temperature | |
| | Normal temperature |
| | Low temperature |
| | Do not tumble dry |

| Ironing | |
|--|--|
| The number of dots indicates the ironing temperature | |
| | Hot iron (max sole plate temp. approx. 200°C) |
| | Medium hot iron (max sole plate temp. approx. 150°C) |
| | Cool iron (max sole plate temp. approx. 110°C). Do not steam iron garments carrying this symbol. |
| | Do not iron |

| Professional cleaning | |
|-----------------------|---|
| | Dry clean only. The letters indicate the type of cleaning agent required. |
| | |
| | Professional Wet Clean only |
| | Do not dry clean |


| Bleaching | |
|-----------|--|
| | Any oxidising bleaching agent can be used |
| | Only use an oxygen based bleach or a non-chlorine bleach |
| | Do not bleach |

Changing the programme sequence


Cancelling a programme

You can cancel a programme at any time after it has started.


Turn the programme selector to *Finish*.

The water will drain away. The laundry can be unloaded when  appears in the display.

Interrupting a programme

- Switch the machine off with the  button.

To continue with the same programme:

- Switch the machine on with the  button.

Making changes to a programme

After the start of a programme it is no longer possible to select a different programme.

Temperature

It is possible to select a different temperature up to 6 minutes after the programme has started.

Spin speed

It is possible to change the spin speed at any time.

Additional options

It is possible to select or deselect the *Water plus* additional option up to 6 minutes after the programme has started.

Changing the programme sequence

Adding or removing laundry after a programme has started

- Press the *Door* button in until the drum door springs open.
- Add or remove items.
- Close the door.

The programme will continue automatically.

Please note:

Once a programme has started the machine cannot recognise any adjustment to the load.

For this reason, if laundry is added or removed after the start of a programme, the machine will always complete the programme cycle assuming a full load

This can lead to an increase in the programme duration shown in the display.

The door cannot be opened if:

- the suds temperature is above 55°C.
- the water is above a certain level.
- the final spin is being carried out.



The correct detergent

All modern detergents produced for automatic washing machines are suitable. Use dispensing aids, e.g. balls, if these are supplied with the detergent. Tablets are suitable for full loads, but note that it may be impractical to reduce tablets for smaller loads. Some tablets do not dissolve as rapidly as others, and may not be suitable for programmes with short durations.



Do not use biological detergents on silk as the enzymes may damage the silk! Instructions for use and recommended dosage amounts are given on the detergent packaging.

See "Optional accessories" at the end of this booklet for details of Miele branded care products including detergents and fabric conditioner.

Detergent

| | Universal detergent | Detergent for coloureds | Detergent for delicates | Specialist detergent* | Proofing agent** | Fabric conditioner |
|---|---------------------|-------------------------|-------------------------|-----------------------|------------------|--------------------|
| Cottons | X | X | – | – | – | X |
| Minimum iron | X | X | – | – | – | X |
| Delicates | X | X | X | – | – | X |
| Automatic | X | X | – | – | – | X |
| Dark garments ¹⁾ | X | X | X | – | – | X |
| Shirts | X | X | – | – | – | X |
| Denim ¹⁾ | X | X | X | – | – | X |
| Express ¹⁾ | X | X | – | – | – | X |
| Silks  | – | – | – | X | – | X |
| Woolens  | – | – | – | X | – | X |
| Separate rinse/ Starch | – | – | – | X | – | X |

¹⁾ Liquid detergent


For programmes with a pre-wash you will need to purchase a special container from the Miele Spare Parts Department which sits in the main wash compartment . Add liquid detergent to this container for the main wash and to compartment  for the pre-wash

²⁾ Use powder detergent

* Specialist detergent

Detergent designed specifically for the wash programme or type of fabric.

** Only use proofing agents containing fluorochemical compounds which are stated by the manufacturer as being "suitable for use on membrane textiles".

Do not use proofing agents which contain paraffin. Add proofing agents to compartment .

The right amount to dispense will depend on the following:

- The quantity of laundry.
- The soiling level of the laundry.

Lightly soiled

No visible dirt or stains. Possibly slight body odour.

Normally soiled

Visibly dirty and/or just a few slight stains.

Heavily soiled

Visible dirt and stains and/or dried on soiling.

- The water hardness level.
Check with your local water supplier if you do not know the hardness level in your area.

Water hardness levels

| Hardness scale | Hardness level mmol/l | German °d |
|----------------|-----------------------|-----------|
| I (soft) | 0 - 1.5 | 0 - 8.4 |
| II (medium) | 1.5 - 2.5 | 8.4 - 14 |
| III (hard) | Above 2.5 | Above 14 |

Refill packs of detergent

When purchasing detergent buy refill packs wherever possible. This helps reduce the amount of waste packaging.


Water softeners

A water softener can be used to cut down on the use of detergents in hard water areas. Dispense according to the amount specified on the packaging. First add detergent and then the water softener.

Miele branded water softening tablets are available from Miele. See "Optional accessories".

Use a quantity of detergent as for soft water.

Washing with several components

If you wash using several components (e.g. special application detergents), we recommend always dispensing the agents into compartment  in the following order:

1. Detergent
2. Water softener
3. Stain remover

This way the agents are distributed more evenly.


Detergent

Fabric conditioners and liquid starch

Fabric conditioners make garments soft to handle and help prevent static cling when tumble drying.

Starch stiffens and gives body to items of laundry, e.g. shirts, tablecloths and bed linen.

Automatic dispensing of fabric conditioner or liquid starch to laundry at the end of a programme



- Add the fabric conditioner or liquid starch to compartment ☼. **Do not exceed the maximum level mark.**

It will be automatically dispensed in the last rinse. At the end of the programme a small amount of water remains in the fabric conditioner compartment ☼.


If starching frequently, the dispenser compartment and especially the siphon tube and fabric conditioner channel will need regular cleaning to remove any residual starch. See "Cleaning the detergent dispenser drawer". Do not add powder starch formulations or viscous liquid starch to the ☼ compartment as it will clog up. See below.


Adding fabric conditioner or starch separately

- Dispense in accordance with manufacturer's instructions on the packaging.
- Add powder or viscous starch to compartment ▮.
- Add the fabric conditioner or liquid starch to compartment ☼.
- Turn the programme selector to *Separate rinse/Starch*
- Select a spin speed.
- Press the *Start* button.

Colour run and dye removers / dyes

- Do not use colour run or dye removers in this washing machine.
- Dyes suitable for use in domestic washing machines can be used. However, please note that the salt used in the dyeing process can cause corrosion to stainless steel components in the machine if you dye frequently. Always observe the manufacturer's instructions carefully.

 Disconnect the machine from the mains electricity supply and withdraw the plug from the socket before cleaning the machine.


 The washing machine must not be hosed down.

A range of Miele branded cleaning and conditioning agents is available to order from the Miele Spare Parts Department, or via the internet on www.miele-shop.com.

External casing and control panel

Clean the casing and the control panel using an E-Cloth, or with a mild, non-abrasive cleaning agent or soap and water using a well wrung-out cloth. Wipe dry with a soft cloth.

- The drum and any stainless steel outer panels can be cleaned using a suitable stainless-steel cleaning agent following the instructions on the packaging.


 Do not use solvents, abrasive cleaners, glass cleaners or all-purpose cleaning agents. These could damage plastic surfaces and other parts.

Extra cleaning

Carry out a hot wash (60°C or above) with powder detergent approx. every 6 weeks to help prevent deposits building up in the machine. These can occur when washing is mainly done at low temperatures, and can lead to unpleasant smells. If you have no reason to wash occasionally at high temperatures, then run a Cottons 90°C programme with detergent but no laundry at regular intervals.


Cleaning the detergent dispenser drawer

For hygiene reasons, clean the entire drawer at regular intervals.




- Pull out the detergent dispenser drawer until a resistance is felt. Press down the release catch and at the same time pull the drawer right out of the machine.
- Clean the detergent drawer with hot water.

Cleaning and care




■ Clean the siphon.

1. Remove the siphon from compartment  and rinse under hot running water. Clean the siphon tube in the same way.
2. Replace the siphon.

If starching frequently, thoroughly clean the siphon and siphon tube regularly. A build-up of starch will cause them to get clogged.

Cleaning the detergent dispenser drawer housing



- Use a bottle brush to remove detergent residues and limescale from the jets inside the detergent dispenser drawer housing.


Cleaning the water inlet filters

The washing machine has two filters to protect the inlet valves.

These filters should be checked every six months or so, or more often if there are frequent interruptions to the water supply.

To clean the filter in the union in the open end of the inlet hose:


- First turn off the stopcock.
- Unscrew the inlet hose from the stopcock.



- Remove rubber seal **1** from the recess.
- Using pointed pliers, take hold of plastic filter bar **2**, remove the filter and clean it.
- Put the filter and seal back in the reverse order and reconnect the hose.
- Turn on the stopcock and check the connection is watertight. If it leaks, tighten the connection.

To clean the filter in the water inlet valve:

- Using pliers, carefully loosen the ribbed plastic nut on the inlet valve and unscrew.




- Use pointed nose pliers to withdraw the plastic filter by the bar (see illustration). Clean, put back and secure.

The two filters **must** be put back in place after cleaning.

Problem solving guide

With the help of the following notes, minor faults in the performance of the machine, some of which may result from incorrect operation, can be put right without contacting the Service Department.

 Repair work to electrical appliances should only be carried out by a suitably qualified person in strict accordance with current local and national safety regulations. Repairs and other work by unqualified persons could be dangerous. The manufacturer cannot be held liable for unauthorised work.

The programme does not start


| Problem | Possible cause | Remedy |
|---|-----------------------------------|--|
| <i>0</i> is not in the display or the <i>Start</i> button is not flashing. | There is no power to the machine. | Check whether <ul style="list-style-type: none">– the mains plug is plugged in and switched on.– the fuse or circuit breaker has tripped.– the drum door is closed properly. |


The wash programme stops and a fault indicator light comes on

| Problem | Possible cause | Remedy ❶ |
|--|---|--|
| The <i>Check inlet/ drainage</i> light flashes and <i>F10</i> shows in the display. | The water outlet is blocked. | Clean the drain filter and the drain pump as described in "Problem solving guide – Opening the drum door in the event of a blocked water outlet and/or a power failure". |
| | The drain hose has been fixed too high. | The maximum delivery head is 1 m. |
| | The water inlet is blocked. | Open the stopcock. |
| | The filter in the water inlet hose is dirty | Clean the filter. |
| | The water safety system has reacted. | Call Miele Service. |


- ❶ To switch off the fault indicator: Switch the washing machine off with the  button and turn the programme selector to *Finish*.

Problem solving guide

| General problems | | |
|---|--|--|
| Problem | Possible cause | Remedy |
| The machine shakes during the spin cycle. | The machine feet are not level. | Level the machine (see "Installation and connection"). |
| The laundry has not been spun properly and is still wet. | The machine detected an imbalance during the final spin and reduced the spin speed automatically. | Include both large and small items in the load as this will give better distribution. |
| The laundry has not been spun satisfactorily. | The spin speed selected was too low. | Select a higher spin speed next time. |
| The pump makes strange noises. | This is not a fault! These noises occur at the end of a pump sequence as a normal part of the operation. | |
| There is a lot of detergent residue in the detergent drawer. | The water pressure is too low. | <ul style="list-style-type: none"> – Clean the filter in the water inlet. – Select Water plus. |
| | Powder detergent used with water softeners can be sticky. | <ul style="list-style-type: none"> – Clean the detergent drawer. – Add washing powder and then add the water softener. |
| Fabric conditioner is not completely dispensed or too much water remains in the  compartment. | The siphon tube is not correctly positioned or is clogged up. | Clean the siphon, (see "Cleaning and care - Cleaning the detergent dispenser drawer"). |
| When laundry is dry it feels hard to the touch. | Too vigorous wash action. | Programme in gentle action and more water. |
| | Not enough detergent used. | Increase detergent dose to prevent limescale build up in laundry. |
| | No fabric conditioner used. | Use fabric conditioner in last rinse. |

| An unsatisfactory wash result | | |
|---|--|--|
| Problem | Possible cause | Remedy |
| Liquid detergent does not give the required result. | Liquid detergents usually contain no bleaching agents. They do not remove fruit, coffee and tea stains. | <ul style="list-style-type: none"> – Use a general purpose detergent containing a bleaching agent. – Pour stain removers into compartment  of the dispenser drawer and liquid detergent into a dispenser ball. – Never put stain removers and liquid detergent together in the dispenser drawer. |
| Grey, greasy particles cling to washed laundry. | Insufficient amounts of detergent were used to break down the particles of grease in heavily soiled laundry. | <ul style="list-style-type: none"> – Use more detergent. – Before washing the next load run a <i>Cottons 90°C</i> programme with powder detergent but without a load. |
| White residues which look like powder detergent are seen on dark textiles after washing. | The detergent contained compounds (zeolites) to aid water softening which are not soluble in water. They have ended up on the laundry. | <ul style="list-style-type: none"> – Try and brush off the residues with a soft brush once the laundry is dry. – Wash dark textiles using a detergent which contains no zeolites. Liquid detergents usually contain no zeolites. – Use the <i>Dark garments</i> programme. |
| Clothes are coming out creased. | The machine was overloaded. | <ul style="list-style-type: none"> – Reduce quantity of clothes in drum. |
| | The wrong programme was used. | <ul style="list-style-type: none"> – Check care labels and the programme chart. – Use easy iron conditioners. |


Problem solving guide

| The drum door does not open when you press the Door button | |
|--|---|
| Possible cause | Remedy |
| The washing machine is not connected to the electricity supply and/or is not switched on. | Insert the plug in the socket and switch on and / or switch the machine on with the  button. |
| Power cut. | Open the drum door as described in "Opening the drum door in the event of a blocked drain outlet and/or power failure". |
| The door was not correctly engaged. | Press hard against the lock side of the drum door and then press the <i>Door</i> button. |
| There is still water in the drum and the machine is unable to drain. | Clean the drain filter and the drain pump. |
| For safety reasons the drum door cannot be opened if the suds temperature is higher than 55°C. | |


Opening the drum door in the event of a blocked drain outlet and/or power failure

- Switch the washing machine off.

There is a lever behind the detergent drawer fascia panel.




- Remove the lever.



- Use it to open the access flap.

Blocked drain outlet

If the drain outlet is blocked, up to 25 litres of water will be retained in the machine.

 Caution: if laundry has been washed at a high temperature, water draining out of the machine will still be hot. Danger of scalding!

Procedure for draining the machine



- Place a suitable container under the access flap.

When draining water from the machine, do **not** unscrew the drain filter completely or take it right out.


- Slowly and carefully unscrew the drain filter to let the water out.

If you need to interrupt the flow of water:


- Tighten the drain filter back up again.

Problem solving guide


Once the flow of water ceases:



- Remove the drain filter completely.
- Clean it thoroughly.





- Remove any foreign objects (e.g. buttons, coins, etc.) and fluff from the filter housing. Turn the impeller by hand to check that it rotates freely. Any foreign object causing an obstruction should be removed.
- Put the drain filter back in place and secure.

 Make sure the drain filter is securely tightened. Otherwise there is a risk of water leakage during use.

To avoid loss of detergent, pour approx. 2 litres of water into the detergent dispenser drawer after cleaning the drain filter. Excess water will be pumped out automatically before the next wash programme.

Opening the drum door

 Always make sure that the drum is stationary before reaching into the machine to remove laundry. Reaching into a moving drum is extremely dangerous.




- Pull the emergency release downwards (see illustration). The drum door will open.

In the event of any faults which you cannot remedy yourself, please contact:

- your Miele Dealer or
- Miele (see back cover for contact details).

When contacting your Dealer or Miele, please quote the model and serial number of your machine, both of which are shown on the data plate visible above the porthole glass when the door is open.



N.B. A call-out charge will be applied for service visits where the problem could have been resolved as described in these instructions.

Future updates (PC)

The indicator light marked PC is the interface used by Miele service technicians during servicing work for testing purposes and for updating the machine's programme data.

Guarantee

For information on the appliance guarantee specific to your country please contact Miele. See back cover for contact details.

In the U.K. your appliance is guaranteed for 2 years from the date of purchase. However, you must activate your cover by calling 0845 365 6640 or registering online at www.miele.co.uk.


Optional spare parts and accessories

Optional spare parts and accessories for this washing machine are available from your Miele Dealer, the Miele Spare Parts Department or via the internet at www.miele-shop.com.

Please note that telephone calls may be monitored and recorded for training purposes.

Installation and connection

Front view



① Inlet hose (tested to withstand pressure of at least 7,000 kPa)

② Electricity supply cable

③ - ⑥ Flexible drain hose (with detachable elbow)

⑦ Control panel

⑧ Detergent dispenser drawer


⑨ Drum door

⑩ Access to drain filter, drain pump and emergency release

⑪ Handle recesses for moving the machine

⑫ Four height adjustable feet

Rear view



① Protruding lid for holding when moving the machine

② Electricity supply cable

③ Inlet hose (tested to withstand pressure of at least 7,000 kPa)

④ Drain hose

⑤ Transit bar covers

⑥ Retaining clip for inlet hose and drain hose

⑦ Retaining clips for transit bars when removed

Installation and connection

Installation surface

A concrete floor is the most suitable installation surface for a washing machine, being far less prone to vibration during the spin cycle than wooden floorboards or a carpeted surface.

Please note the following points:

- The machine must be level and securely positioned.
- To avoid vibrations during spinning, the machine should not be installed on soft floor coverings.

If installing on a wooden joist floor:

- We recommend a plywood base (at least 59x52x3 cm). The base should span several joists and be bolted to the joists and not only to the floorboards. Check for the presence of pipes and cables.

If possible, install the machine in a corner, as this is usually the most stable part of the floor.


⚠ If the machine is installed on a raised plinth, it **has to be secured** against slippage during spinning using retaining clips (available from the Miele Spare Parts Dept). Otherwise there is a danger of the machine moving and falling off the plinth.

Installing the washing machine

To manoeuvre the machine out of its packing case to its installation site hold it by the edge of the lid where it protrudes to the rear of the washing machine as well as by the handle recesses at the front.


⚠ Ensure that the machine feet and the floor are dry to prevent the machine from slipping during the spin cycle.

Removing the transit bars




- To remove the left and right covers
 1. Use a screwdriver to prise out the cover as illustrated.
 2. Pull the cover forwards to remove.


Installation and connection




- Using the spanner supplied turn the left-hand transit bar 90°, then



- Turn the right-hand transit bar 90°, then





- withdraw the transit bar.




- withdraw the transit bar.

Installation and connection


 To avoid the risk of injury the holes for the transit bars must be covered after the transit bars have been removed.



- Fit the covers on to the two holes. Then plug the holes as shown with the caps.



- Secure the transit bars to the back of the washing machine. Make sure that holes **B** are fitted over retainers **A**.

 The washing machine must not be moved without the transit bars in place. Store them as shown or keep them in a safe place for future use. They must be re-fitted if the machine is to be moved again (e.g. when moving house).

Re-fitting the transit bars

Re-fitting is carried out by reversing the procedure.


Levelling the machine

The machine must stand perfectly level on all four feet to ensure safe and proper operation.


Incorrect installation may increase electricity and water consumption and may cause the machine to move about.

Screwing out and adjusting the feet


The four adjustable screw feet are used to level the machine. All four feet are screwed in when the machine is delivered.



- Using the spanner supplied turn counter nut **2** in a clockwise direction. Then turn counter nut **2** together with foot **1** to unscrew.



- Use a spirit level to check the machine is standing level.
- Hold foot **1** securely with a pipe wrench. Turn counter nut **2** again using the spanner supplied until it sits firmly up against the housing.

 All four counter nuts must be firmly up against the housing. Please also check this for the feet which did not need adjustment. Otherwise there is the danger of the machine moving about.

Installation and connection

The fitting of building-under kits* and stacking kits* must only be undertaken by qualified and competent persons, in accordance with the instructions supplied with the kit.

Building under a continuous worktop/in a kitchen run

If you wish to push your machine under a worktop and there is space to do this **without removing the lid**, the conversion kit is not necessary.

- Otherwise a special building-under conversion kit* is required. To ensure electrical safety, the washing machine lid must be replaced by the cover plate supplied with the conversion kit.
- For installation under a work surface 900/910 mm from the floor, a raising kit* is required.
- Connections for electricity, water and drainage should be installed in such a way that they remain accessible when the machine is in place.


Fitting instructions are supplied with the conversion kit.

All parts marked* are available from your Dealer, the Miele Spare Parts Department or via the internet at www.miele-shop.com.

Washer and Dryer stack

A Miele tumble dryer can be stacked with the washing machine. A "WTV" stacking kit* is necessary.

Please note:



a Safety distance to wall:
at least 2 cm

b Height:
Stacking kit with pull-out shelf:
approx. 169 cm
Stacking kit without pull-out shelf:
approx. 170 cm

The Miele water safety system

The Miele water safety system protects the washing machine from water damage.

The system consists of three main components:

- 1) the inlet hose
- 2) the electronic unit
- 3) the drain hose

1) Inlet hose

The inlet hose is tested to withstand pressure of more than 7,000 kPa

2) Electronic unit

If, during the water intake, the electronic unit has not detected an increase in the water level in the suds container after 90 seconds, the inlet valve is closed again

- Overflow protection

This prevents the washing machine taking in too much water. If the water level exceeds a certain level, the drain pump switches in and pumps the excess water away.

3) Drain hose

The drain hose is protected by a ventilation system which prevents the washing machine from being emptied completely.

Installation and connection

Connection to the water supply

The machine should be connected to a mains water supply in accordance with local and national safety regulations. The German authorities do not require it to have a non-return valve as it has been designed to comply with DIN regulations.


The machine is designed to operate with a flow pressure of between 100 kPa and 1,000 kPa. If it is higher than 1,000 kPa it is essential to fit a reducer valve.

Connection to the mains water supply should incorporate a mains stopcock with $\frac{3}{4}$ " thread. The stopcock should be fitted by a qualified plumber.

In order to protect the water inlet valve, the two dirt filters - one in the open end of the inlet hose, one at the inlet point in the machine must not be removed.

Extension hose

Longer hoses 2.5 or 4.0 m in length are available from your Miele dealer or the Miele Spare Parts Department as optional extras.

 The connection point is subject to mains water pressure. Turn on the stopcock slowly and check for leaks. Correct the position of the washer and union if appropriate.

The washing machine is **not** suitable for connection to a hot water supply.

Maintenance and care

Only use a genuine Miele hose should you ever need a replacement or extension. These are tested to withstand pressure of at least 7,000 kPa.

Connection to the drainage system

The machine drains via a drain pump with a delivery head of 1 metre*. The drain hose must not be kinked as this restricts drainage. The elbow at the end can be detached.

If required, the drain hose can be extended to a length of 5 m. The necessary parts can be purchased from the Miele Spare Parts Department or your Miele dealer.

* For a delivery head of more than 1 m (up to a max. of 1.8 m) a replacement drain pump will need to be fitted. Please contact the Miele Spare Parts Department or your Miele Dealer.


Drain hose connection:

1. Direct into a sink or basin:

Please note the following:

- Hook the hose over the edge and secure.
 - Make sure that the water can drain away freely without hindrance. Otherwise there is a risk of water overflowing or of some of the drained water being sucked back into the machine.
2. Connected securely to a plastic drain pipe with a rubber nipple. There is no need to use a non-return valve.
 3. Connected securely to a floor gully.
 4. Connected securely to a standpipe.

Please note:



- ① Adapter
- ② Nut
- ③ Hose clip
- ④ End of the hose

- Fit adapter ① to the sink drain outlet using nut ②.
- Attach the end of hose ④ to adapter ①.
- Use a screwdriver to tighten hose clip ③ up close to the nut.

Installation and connection

Electrical connection U.K.

All electrical work should be carried out by a suitably qualified and competent person, in strict accordance with current national and local safety regulations (BS 7671 in the UK).

Ensure power is not supplied to the appliance until after installation work has been carried out.

The appliance is supplied with a mains cable with moulded plug ready for connection to a 230-240V mains supply.

Please ensure the connection data quoted on the data plate match the household mains supply.

Connection should be made via a suitable switched socket which is easily accessible after installation.

For extra safety it is advisable to protect the appliance with a suitable residual current device (RCD). Contact a qualified electrician for advice.

Do not connect via an extension lead. Extension leads do not guarantee the required safety of the appliance (e.g. danger of overheating).

Non-rewireable plugs BS 1363

The fuse cover must be refitted when changing the fuse, and if the fuse cover is lost, the plug must not be used until a suitable replacement is obtained. The colour of the correct replacement cover is that of the coloured insert in the base of the plug, or the colour that is embossed in words on the base of the plug (as applicable to the design of plug fitted).

Replacement fuses should be ASTA approved to BS 1362 and have the correct rating. Replacement fuses and fuse covers may be purchased from your local electrical supplier.

WARNING: THIS APPLIANCE MUST BE EARTHED

Consumption data

| | | Load | Consumption data | | | |
|----------------------|-------|--------|------------------|--------------------|------------|----------------------|
| | | | Energy in kWh | Water in litres | Duration | Residual moisture |
| Cottons | 90°C | 7.0 kg | 2.20 | 51 | 2 h 09 min | 52% |
| | 60°C* | 7.0 kg | 1.10 | 51 | 2 h 14 min | 52% |
| | 60°C* | 3.5 kg | 0.89 | 38 | 1 h 58 min | 52% |
| | 40°C | 7.0 kg | 0.72 | 56 | 2 h 29 min | 52% |
| | 40°C* | 3.5 kg | 0.59 | 56 | 2 h 15 min | 52% |
| Minimum iron | 40°C | 3.0 kg | 0.50 | 55 | 1 h 19 min | 30% |
| Delicates | 30°C | 2.0 kg | 0.38 | 69 | 59 min | – |
| Automatic | 40°C | 3.5 kg | | | 1 h 13 min | – |
| Dark garments | 40°C | 3.0 kg | 0.60 | 60 | 1 h 13 min | – |
| Shirts | 40°C | 2.0 kg | | 59 | 57 min | – |
| Denim | 40°C | 3.0 kg | 0.50 | 52 | 1 h 00 min | – |
| Express | 40°C | 3.0 kg | 0.30 | 34 | 34 min | – |
| Silks 🧺 | 30°C | 1.0 kg | 0.25 | 39 | 36 min | – |
| Woollens 🧺 | 30°C | 2.0 kg | 0.23 | 39 | 39 min | – |

Notes for test institutes:

* Test programme in accordance with EN 60456 and energy label with Directive 1061/2010.

Consumption data can vary from the nominal values given depending on water pressure, water hardness, water inlet temperature, room temperature, type and volume of load, fluctuations in the electricity supply and any extra options selected.

Technical data

| | |
|---|------------------------|
| Height | 850 mm |
| Width | 595 mm |
| Depth | 580 mm |
| Depth with door open | 975 mm |
| Height for building under | 820 mm |
| Width for building under | 600 mm |
| Depth for building under | 600 mm |
| Weight | 101 kg |
| Capacity | 7 kg dry laundry |
| Voltage | see data plate |
| Connected load | see data plate |
| Fuse rating | see data plate / plug |
| Consumption data | see "Consumption data" |
| Water flow pressure minimum | 100 kPa (1 bar) |
| Water flow pressure maximum | 1000 kPa (10 bar) |
| Inlet hose length | 1.60 m |
| Drain hose length | 1.50 m |
| Mains connection cable length | 1.60 m |
| Delivery head max. | 1.00 m |
| Maximum drainage length | 5.00 m |
| Test certificates awarded | see data plate |
| Power consumption when switched off | 0.20 W |
| Power consumption when not switched off | 0.50 W |

The programmable functions can be used to alter the machine's electronics to suit changing requirements. Programmable functions can be altered at any time.

The programmable functions are accessed via the *Start* button and the programme selector.

Water plus system

This setting is used to specify one of three options for the *Water plus* button.

P2:

(Factory default)

The water level is increased in the wash and rinse stages.

P3:

An extra rinse is carried out.

P4:

The water intake is increased in the wash and rinse stages and an extra rinse is carried out.

Follow steps ① to ⑦ to programme and store in memory.

Before you begin, ensure that:

- The washing machine is switched off.
- The machine door is closed properly.
- The programme selector is at *Finish*.

① Press the *Start* button and keep it pressed in whilst carrying out steps ②-③.

② Switch the machine on with the $\frac{1}{\Delta\Delta}$ button.

③ Wait until the indicator light for the *Start* button lights up constantly . . .

④ . . . and then release the *Start* button.

⑤ Turn the programme selector to *Cottons* $\langle 60^{\circ}\text{C} \rangle$.

A *P* will flash in the display alternating with the number 2, 3 or 4.

⑥ Each subsequent press on the *Start* button selects a different setting.

The number flashing in the display indicates the option selected.

⑦ Switch the washing machine off using the $\frac{1}{\Delta\Delta}$ button.

Programmable functions

Gentle action

Activating Gentle action reduces the drum action and is suitable for washing slightly soiled items more gently. It should be activated for garments with a single bar under the "bucket" in the care label and for articles which feel too hard after they have been dried.

Gentle action can be activated for the *Cottons* and the *Minimum iron* programmes.

The washing machine is delivered with the Gentle action setting deactivated.

Follow steps ① to ⑦ to programme and store in memory.

Before you begin, ensure that:

- The washing machine is switched off.
- The machine door is closed properly.
- The programme selector is at *Finish*.

① Press the *Start* button and keep it pressed in whilst carrying out steps ②-③.

② Switch the machine on with the $\frac{1}{0}$ button.

③ Wait until the indicator light for the *Start* button lights up constantly . . .

④ . . . and then release the *Start* button.

⑤ Turn the programme selector to *Cottons* $\langle 40^{\circ}\text{C} \rangle$.

A *P* will flash in the display alternating with the number 0 or 1.

0 = deactivated

1 = activated

⑥ Each subsequent press on the *Start* button selects a different setting.

The number flashing in the display indicates the option selected.

⑦ Switch the washing machine off using the $\frac{1}{0}$ button.

Suds cooling

When this is activated, additional water flows into the drum at the end of the main wash to cool the suds down. Hot suds can damage plastic drainage pipes.

Suds cooling takes place when the *Cottons 90°C* programme is selected.

Suds cooling should be activated:

- to prevent the danger of scalding if the drain hose is hooked over the edge of a sink or basin.
- where the drainage pipes do not comply with DIN 1986.

The machine is delivered with Suds cooling deactivated.

Follow steps ① to ⑦ to programme and store in memory.

Before you begin, ensure that:

- The washing machine is switched off.
- The machine door is closed properly.
- The programme selector is at *Finish*.

① Press the *Start* button and keep it pressed in whilst carrying out steps ②-③.

② Switch the machine on with the $\frac{1}{2}$ button.

③ Wait until the indicator light for the *Start* button lights up constantly . . .

④ . . . and then release the *Start* button.

⑤ Turn the programme selector to *Cottons 30°C*.

A *P* will flash in the display alternating with the number 0 or 1.

0 = deactivated

1 = activated

⑥ Each subsequent press on the *Start* button selects a different setting.

The number flashing in the display indicates the option selected.

⑦ Switch the washing machine off using the $\frac{1}{2}$ button.

Programmable functions

Memory function

If an extra option is selected for a programme, and / or the spin speed is altered, the machine stores these changes in memory at the start of a programme.

When that particular programme is chosen again, the washing machine will display the extra option and / or spin speed which have been stored for that programme in the memory.

The machine is delivered with the memory function deactivated.

Follow steps ① to ⑦ to programme and store in memory.

Before you begin, ensure that:

- The washing machine is switched off.
- The machine door is closed properly.
- The programme selector is at *Finish*.

① Press the *Start* button and keep it pressed in whilst carrying out steps ②-③.

② Switch the machine on with the $\frac{1}{0}$ button.

③ Wait until the indicator light for the *Start* button lights up constantly . . .

④ . . . and then release the *Start* button.

⑤ Turn the programme selector to *Minimum iron 60°C*.

A *P* will flash in the display alternating with the number *0* or *1*.

0 = deactivated.

1 = activated

⑥ Each subsequent press on the *Start* button selects a different setting.

The number flashing in the display indicates the option selected.

⑦ Switch the washing machine off using the $\frac{1}{0}$ button.

Soak duration

A length of time of between 30 minutes and 2 hours can be programmed in 30 minute increments for the soak process.

If the Soak option is pressed, the selected soak time will be carried out for the period selected before the wash programme is run.

The machine is delivered with a two hour soak time set as standard.

Follow steps ❶ to ❷ to programme and store in memory.

Before you begin, ensure that:

- The washing machine is switched off.
- The machine door is closed properly.
- The programme selector is at *Finish*.

❶ Press the *Start* button and keep it pressed in whilst carrying out steps ❷-❸.

❷ Switch the machine on with the $\Delta \square$ button.

❸ Wait until the indicator light for the *Start* button lights up constantly . . .

❹ . . . and then release the *Start* button.

❺ Turn the programme selector to *Minimum iron 40°C*.

A *P* will flash in the display alternating with the number 1, 2, 3 or 4.

1 = the soak time is 2 hours
(default setting)

2 = the soak time is 1 hour 30 minutes

3 = the soak time is 1 hour

4 = the soak time is 30 minutes

❻ Each subsequent press on the *Start* button selects a different setting.

The number flashing in the display indicates the option selected.

❼ Switch the washing machine off using the $\Delta \square$ button.

Optional accessories

Miele washing machines offer perfect care for your laundry and feature a wide range of special programmes designed to suit the fabric being washed. Miele have also developed a range of specialist CareCollection detergents and conditioning products as well as descaling agent and water softening tablets to offer you a complete package for looking after your machine and caring for your laundry.

The Miele CareCollection detergents and conditioning products are listed below. You can order these and many other useful products via the internet at:



All the products can also be ordered from Miele (see back cover for contact details).

CareCollection

Miele specialist detergents

"Outdoor wear"

This specialist detergent will clean your water-repellent outerwear with care.

"Sportswear"

The Miele Sportswear detergent is designed to clean sportswear and remove odours whilst taking care of the special microfibres used in these garments.

"Down Items"

This special-purpose detergent contains a mild tenside and has been specially formulated to keep down-filled items supple and to give them bounce.

Miele proofing agent

This special finishing agent reproofs garments against wind and water and provides a dirt-repellent finish whilst retaining elasticity and breathability.

"UltraWhite" detergent

This multi-purpose powder detergent has excellent stain removal properties and is suitable for white and light coloured laundry as well as heavily soiled coloured items.

"UltraColor" detergent for coloured garments

This liquid detergent is particularly suitable for cleaning coloured and dark garments. The special formulation offers effective stain removal, even at low temperatures, while helping to prevent colours fading.

Liquid detergent "For Delicates"

This liquid detergent is ideal for the gentle treatment of delicate fabrics, such as wool and silk. Its special formulation cleans effectively at temperatures as low as 20°C, while protecting the colour of your delicate garments.

Fabric conditioner

The Miele fabric conditioner will give your laundry a fresh, natural fragrance. It makes garments soft to handle and prevents static build-up during tumble drying.

United Kingdom

Miele Co. Ltd.
Fairacres, Marcham Road
Abingdon, Oxon, OX14 1TW
Tel: 0845 365 0555, Fax: 0845 365 0777
Customer Contact Centre Tel: 0845 365 6600
E-mail: info@miele.co.uk
Internet: www.miele.co.uk

Australia

Miele Australia Pty. Ltd.
ABN 96 005 635 398
1 Gilbert Park Drive, Knoxfield, VIC 3180
Tel: 1300 464 353, Fax: (03) 9764 7149
Internet: www.miele.com.au

China

Miele (Shanghai) Trading Ltd.
1-3 Floor, No. 82 Shi Men Yi Road
Jing' an District
200040 Shanghai, PRC
Tel: +86 21 6157 3500, Fax: +86 21 6157 3511
E-mail: mieleshanghai@cn.miele.com
Internet: www.miele.cn

Miele (Hong Kong) Limited

41/F - 4101, Manhattan Place
23 Wang Tai Road
Kowloon Bay
Hong Kong
Tel: (852) 2610 1331, Fax: (852) 2610 1013
Email: mielehk@miele.com.hk

India

Miele India Pvt. Ltd.
Ground Floor, Copia Corporate Suites
Plot No. 9, Jasola
New Delhi - 110025
Tel: 011-46 900 000, Fax: 011-46 900 001
E-mail: customercare@miele.in, Internet: www.miele.in

Ireland

Miele Ireland Ltd.
2024 Bianconi Avenue
Citywest Business Campus, Dublin 24
Tel: (01) 461 07 10, Fax: (01) 461 07 97
E-Mail: info@miele.ie, Internet: www.miele.ie

Manufacturer: Miele & Cie. KG

Carl-Miele-Straße 29, 33332 Gütersloh, Germany

Miele

Malaysia

Miele Sdn Bhd
Suite 12-2, Level 12
Menara SapuraKencana Petroleum
Solaris Dutamas No. 1, Jalan Dutamas 1
50480 Kuala Lumpur, Malaysia
Phone: +603-6209-0288
Fax: +603-6205-3768

New Zealand

Miele New Zealand Limited
Unit L, 10-20 Sylvia Park Road
Mt. Wellington, 1060, Auckland, NZ
Tel: 0800 264 353, Fax: 0800 463 453
Internet: www.miele.co.nz

Singapore

Miele Southeast Asia
Miele Pte. Ltd.
163 Penang Road
04 - 02/03 Winsland House II
Singapore 238463
Tel: +65 6735 1191, Fax: +65 6735 1161
E-Mail: infosea@miele.com.sg
Internet: www.miele.sg

South Africa

Miele (Pty) Ltd
63 Peter Place, Bryanston 2194
P.O. Box 69434, Bryanston 2021
Tel: (011) 875 9000, Fax: (011) 875 9035
E-mail: info@miele.co.za
Internet: www.miele.co.za

United Arab Emirates

Miele Appliances Ltd.
P.O. Box 11 47 82
Gold & Diamond Park
Sheikh Zayed Road
Building 6 / Offices Nos. 6-214 to 6-220
Dubai
Tel: +971-4-341 84 44
Fax: +971-4-341 88 52
E-Mail: info@miele.ae, Internet: www.miele.ae