


User Guide



### harman / kardon<sup>®</sup> Designed to Entertain<sup>®</sup>

# harman/kardon<sup>®</sup>


Designed to Entertain.

## HTFS 3/E Speaker stands

### **ASSEMBLY INSTRUCTIONS**

Note: HTFS 3/E stands are for use with HKTS 20, HKTS 30, HKTS 60 and HKTS 200 satellite speakers (not included)

1. Attach a stand rail to a stand base




### ASSEMBLY

# <complex-block>


Wire (included with speakers)

### 2. Attach a speaker adapter to the stand rail



### 4. Remove the speaker's base

### HKTS 20 / HKTS 30 / HKTS 60 / HKTS 200 Speakers




### 5. Connect the speaker wire to the speaker


### HKTS 20 / HKTS 30 / HKTS 60 / HKTS 200 Speakers


### A. Push cap down

### B. Insert bare wire

C. Release cap








# Slide speaker onto stand rail

Fit speaker rails onto grooves in stand rail

6. Attach the speaker to the stand rail



7. Bring the speaker wire out of the base

Features, specifications and appearance are subject to change without notice.

Harman Kardon is a trademark of Harman International Industries, Incorporated, registered in the United States and/or other countries. Designed to Entertain is a trademark of Harman International Industries, Incorporated.

Harman International

 $\ensuremath{\mathbb{C}}$  2009 Harman International Industries, Incorporated. All rights reserved.

### Harman International

Harman Consumer Group, Inc. 8500 Balboa Boulevard, Northridge, CA 91329 USA 516.255.4545 (USA only)

www.harmankardon.com

© 2009 Harman International Industries, Incorporated. All rights reserved. Tous droits réservés.

Part No. 444020-001, 444021-001