

socket homeplug

Package content


Installation guide

Register online and get
a free **10 year** warranty

www.sitecom.com/warranty

UK Full manual available
FR Manuel complet est disponible
DE Ausführliche Anleitung erhältlich
NL Volledige handleiding beschikbaar
IT Manuale completo disponibile
ES Manual completo disponible
PT Manual completo disponível
RU Полное руководство доступно

www.sitecom.com/helpdesk



Setup the homeplugs


FR Installation des fiches Homeplug
DE Einrichten der Homeplugs
NL Homeplugs instellen

IT Configurare gli homeplug
ES Colocar los homeplugs
PT Configurar os homeplugs

RU Вставьте штекеры в разъемы

A


1= New homeplug




FR 1= Nouvelle fiche Homeplug
DE 1= Neuer Homeplug
NL 1= Nieuwe homeplug
IT 1= Nuovo homeplug
ES 1= Nuevo homeplug
PT 1= Homeplug novo
RU 1= Новый штекер



2= Existing homeplug



FR 2= Fiche Homeplug existante
DE 2= Vorhandener Homeplug
NL 2= Bestaande homeplug
IT 2= Homeplug esistente
ES 2= Homeplug existente
PT 2= Homeplug existente
RU 2= Существующий штекер



Connect and secure your homeplugs

FR Connexion et sécurisation de vos fiches Homeplug
DE Homeplugs verbinden und sichern
NL Verbind en beveilig je homeplugs


IT Collega e rendi sicuri i tuoi Homeplug
ES Conecte y fije bien sus homeplug
PT Ligue e proteja os seus homeplugs

RU Безопасность ваших домашних подключений


B

i


UK Make sure you press the button on both homeplugs within **2 minutes**
FR Veillez à appuyer sur la touche des deux fiches Homeplug dans les **2 minutes**
DE Achten Sie darauf, drücken Sie die Taste auf beiden HomePlugs innerhalb von **2 Minuten**
NL Druk de knoppen snel na elkaar in: binnen **2 minuten**
IT Premere assolutamente il pulsante su entrambi gli homeplug entro **2 minuti**
ES Asegúrese de que pulsa el botón de ambos homeplugs en un plazo de **2 minutos**
PT Não se esqueça de premir o botão em ambos os homeplugs no espaço de **2 minutos**
RU Убедитесь, что кнопка нажата на обоих адаптерах homeplug в течение **2 минут**



10 sec.





UK On release, LEDs will turn off and back on again immediately
FR Lorsque vous la relâchez, les diodes électroluminescentes s'éteignent et se rallument immédiatement
DE Beim Loslassen schaltet sich das LED aus und direkt wieder ein
NL Wanneer je de knop loslaat, gaan de LED's uit en weer aan
IT Al momento del rilascio, i LED si spegneranno e si riaccenderanno immediatamente
ES Cuando lo suelte, los LED se apagarán y volverán a encenderse de nuevo inmediatamente
PT Ao libertá-lo, os LEDs apagam-se e voltam imediatamente a acender
RU При отпускании кнопки светодиодные индикаторы погаснут и сразу загорятся снова



2 sec.


C



2 sec.




D



Done. Enjoy!

Trouble? www.sitecom.com/helpdesk



UK Indication of the LEDs
FR Signification des diodes
DE LED-Anzeigen
NL Indicatie van de LED's
IT Indicatori LED
ES Indicación de los LED
PT Indicação dos LEDs
RU Индикация на светодиодах

Power
Ethernet activity
Homeplug

Reset/Security Button
Reset = 15+ sec.
Security = 2 sec.