

PHILIPS
FC8941





2



7



3



8




4



9





5

























2







		
		
		
		
		
		
		
		
<p>ATTENTION: Only suitable for soft floors (carpets)!</p> <p>ACHTUNG: Nur für weiche Böden (Teppichböden) geeignet!</p> <p>ATTENTION: Convient seulement à des sols mous (tapis) !</p> <p>LET OP: Alleen geschikt voor zachte vloeren (tapijt)!</p> <p>DIKKAT: Yalnızca yumuşak zeminler (halılar) için uygundur!</p>		

