


## Wireless Noise Cancelling Stereo Headset

Reference Guide  
Guide de référence  
Referenzanleitung  
Guia de referencia

Guida di riferimento  
Guia de referencia  
Referentiehandleiding  
Viteopas  
Referansveledding



[http://rd1.sony.net/help/mdr/wf1000xm3/h\\_zz/](http://rd1.sony.net/help/mdr/wf1000xm3/h_zz/)


WF-1000XM3


Made for iPhone | iPod


DIGITAL NC Bluetooth®


©2019 Sony Corporation  
Printed in Malaysia  
<http://www.sony.net/>





A 


B 


C 


D 


E 

F 


G 

H 


I 


J 


K 


L 


M 


N 


O 


P 


Q 


R 


S 


T 


U 


V 


W 


X 


Y 


Z 


AA 


AB 


AC 


AD 


AE 


AF 


AG 


AH 


AI 


AJ 


AK 


AL 


AM 

AN 

AO 

AP 

AQ 

AR 

AS 

AT 

AU 

AV 

AW 

AX 

AY 

AZ 

BA 

BB 

BC 

BD 

BE 

BF 

BG 

BH 

BI 

BJ 

BK 

BL 

BM 

BN 

BP 

BR 

BS 

BT 

BU 

BV 

BW 

BY 

CA 

CB 

CC 

CD 

CE 

CF 

CG 

CH 

CI 

CK 

CL 

CM 

CN 

CO 

CP 

CR 

CS 

CT 

CU 

CV 

CW 

CX 

CY 

DA 

DB 

DC 

DD 

DE 

DF 

DG 

DH 

DI 

DJ 

