

The Alcatel logo is centered on a large blue background. The word "alcatel" is written in a white, lowercase, sans-serif font. The letter 'a' is lowercase, while the 'c' is a stylized lowercase 'c' with a white circle inside it, resembling a camera lens or a globe. The 't' is lowercase, and the 'e' is lowercase. The 'l' is lowercase. The overall logo is clean and modern.

For more information on how to use the phone, please go to www.alcatel-mobile.com and download the complete user manual. Moreover, on the website, you can also find answers to frequently asked questions, upgrade the software via Mobile Upgrade, and so much more.

alcatel

2008D

2008G



Table of contents

1	Getting started	5
1.1	Set up	5
1.2	Power on your phone	11
1.3	Power off your phone.....	11
2	Your mobile	12
2.1	Keys.....	12
2.2	Status bar icons	16
3	Making a call	17
3.1	Placing a call.....	17
3.2	Calling your voicemail	21
3.3	Receiving a call	22
3.4	During a call	23
4	Assistance (SOS)	25
4.1	SOS Contacts.....	25
4.2	SOS Contacts.....	25
5	Menu screen	26
5.1	Access main menu	26
5.2	Access submenu.....	27
6	Contacts.....	28
6.1	Consulting your contacts	28
6.2	Adding a contact.....	29
6.3	Delete a contact.....	31
6.4	Available options.....	32
7	Messages	34
7.1	Write message	34
7.2	Read message	37
7.3	Settings.....	38

8	FM radio	39
9	Camera	43
9.1	Camera	43
9.2	Video	45
10	Alarm	47
11	Tools	49
11.1	Calculator	50
11.2	Calendar	50
11.3	Notes	50
11.4	My files	50
11.5	Bluetooth	50
11.6	Services	51
12	Media	51
12.1	Games	52
12.2	Music	52
12.3	Images	52
12.4	Videos	52
13	Settings	53
13.1	Phone settings	54
13.2	Sound	56
13.3	Call settings	56
13.4	Assistance	59
13.5	Network	59
13.6	Connectivity	61
13.7	Security	61
13.8	Regulatory & Safety	63
13.9	Restore default	63

14 Making the most of your mobile	64
15 Latin input mode	66
Safety and use	67
General information	81
Telephone warranty	83
Troubleshooting	86




www.sar-tick.com

This product meets applicable national SAR limits of 2.0 W/kg. The specific maximum SAR values can be found on page 75 of this user guide. When carrying the product or using it while worn on your body, either use an approved accessory such as a holster or otherwise maintain a distance of 0.5 cm from the body to ensure compliance with RF exposure requirements. Note that the product may be transmitting even if you are not making a phone call.

1 Getting started....


1.1 Set up

Removing or installing the back cover




Installing or removing the battery

Insert and click the battery into place, then close the phone cover.





Unclip the cover, then remove the battery.



Inserting or removing the SIM card


You must insert your SIM card to make phone calls.





Place the SIM card with the chip facing downwards and slide it into its housing. Make sure that it is correctly inserted. To remove the card, press and slide it out.


Inserting or removing the SD card



Charging the battery

The phone can be charged in the following ways:

a.



To charge the phone, you can place the cradle charging connector of the phone to the cradle, then connect battery charger to the cradle and plug into the socket.

b.



Connect battery charger to your phone and plug into the socket

- Be careful not to force the plug into the socket.
- Make sure the battery is correctly inserted before connecting the charger.
- The mains socket must be near to the phone and easily accessible (avoid electric extension cables).



To reduce power consumption and wasting energy, when battery is fully charged, disconnect your charger from the plug; reduce the backlight time, etc.

1.2 Power on your phone


Hold down the  key until the telephone powers on.

1.3 Power off your phone

Hold down the  key from the Home screen.


2 Your mobile.....

2.1 Keys




- | | |
|--------------------------|----------------------|
| 1 Menu/
Direction key | 2 Select/Call
key |
| 3 Back/End call
key | 4 Voicemail
key |

Assistance (SOS) key



Camera



Torch key

Lock key



From Idle screen

- Press: Access Main menu



Call key

- Pick up/Send a call
- Press: Enter Call log (From Idle screen)



- Press: End a call
Return to the Idle screen
Delete character (In Edit mode)

- Press and hold: Power on/off



From Idle screen

- Press: 0
- Press and hold: “+/p/w”

In Edit mode

- Press: Access symbols table
- Press: 0 (when input mode is **Add numbers**)
- Press and hold: 0



From Idle screen

- Press: *

In Edit mode:

- Press: Change input methods
- Press and hold: Access input method list



From Idle screen

- Press: #
- Press and hold: Access speed dial

In Edit mode

- Press: (space)

2.2 Status bar icons ⁽¹⁾



Battery charge level.



Call forwarding activated.



Alarm or appointments programmed.



Level of network reception.



Roaming.



SMS unread.



Silence mode.



Missed calls.



Vibration alert.



Headset mode.

⁽¹⁾ The icons and illustrations in this guide are provided for informational purposes only.



Bluetooth status





GPRS connection status

3


Making a call


3.1 Placing a call

Dial the desired number then press  key to place the call. If you make a mistake, press  key to delete the incorrect digits.




You can also make a call from your call log:

First, press  key from Idle screen to access the call log and choose the contact you want to dial, then select **Options**.




Then select **Call**.





If you want to make a call from phonebook, select **Contacts\Options\Call**.


Select **Contacts** from main menu:



Choose the contact you want to dial, then select **Options**; finally, select **Call**.



To hang up the call, press the  key (Select **End**).





Making an emergency call

If your phone has network coverage, dial emergency number and press the send key to make an emergency call. This works even without a SIM card and without typing the PIN code.



3.2 Calling your voicemail ⁽¹⁾

To access your voicemail, hold down the **1** key. To edit your voicemail, select **Messages\Voicemail\Options>Edit**, then you can edit the voicemail name and number. Finally, select **Save**.





⁽¹⁾ Contact your network operator to check service availability.

3.3 Receiving a call

When you receive an incoming call, press the  key to talk and then hang up using the  key.

Select **Options\Answer** to pick up the call.



If the icon  is displayed, vibration is activated and no ringtone will play.

If the icon  is displayed, the phone neither rings nor vibrates.




The caller's number is displayed if it is transmitted by the network (contact your network operator to check service availability).

Rejecting a call

Press the  key once.

Select **Reject** to reject the call.



3.4 During a call ⁽¹⁾

During a call, following options are available:

- Handfree (Options\Handfree)
- HAC (Hearing Aid Compatibility)

You can adjust the sound level during a call by using the up/down or side key.

⁽¹⁾ Contact your network operator to check service availability.



Move the handset away from your ear while using the "H-free" option because the amplified volume might cause hearing damage.

Handling two calls

- Answering a second call (ensure that "**Call waiting**" is activated, see page 56).

4 Assistance (SOS).....

4.1 SOS Contacts

To add an SOS number to your SOS contacts, please select **Assistance\Contact list** and press **Edit**, then you can edit your SOS numbers.


4.2 SOS Message





From the main menu select **Settings\Assistance\Message** to create an SOS message.

5 Menu screen.....


5.1 Access main menu



Press  from the Idle screen to enter the main menu.

The main menu can be used to select your favourites by pressing  in the left or right direction.



5.2 Access submenu

Access submenus in the phone by pressing  upwards or downwards from the main menu.



6 **Contacts**

6.1 Consulting your contacts

You can access this function by selecting **Contacts** from the main menu.

Searching for a contact

You can search for a contact by typing the initial of their name. Subsequent letters may be added to refine the search.


Viewing a contact

Select a name from your contacts to read the contact information.


6.2 Adding a contact

You can add a new contact to phone or SIM card by pressing **OK**, and select **New** to enter the "New contact" screen.


First, press  from Idle screen to access **Contacts** and select **OK**.



Secondly, select **New**.




Thirdly, you can choose to add the new contact to phone or SIM card.




A screenshot of a dialog box titled "New". It has a white header bar with the text "New". Below the header, there are two options: "To SIM" and "To Phone". At the bottom, there are two buttons: "OK" on the left and "Back" on the right.

Finally, edit the name and numbers and save them.




A screenshot of a form titled "New contact". It has a white header bar with the text "New contact". Below the header, there are three fields: "Name", "Number", and "Options". The "Name" field contains the text "John" and has a small orange icon with the text "!Abc" next to it. The "Number" field is empty. The "Options" field contains the text "Clear".




A screenshot of a form titled "New contact". It has a white header bar with the text "New contact". Below the header, there are three fields: "Name", "Number", and "Options". The "Name" field contains the text "John". The "Number" field contains the text "88888". The "Options" field contains the text "Clear".

6.3 Delete a contact

Select the contact you want to delete and press  to select **Options**.



Then select **Delete** to remove the contact.



6.4 Available options

From the contact list, you can access the following options:

View

View the selected contact.

Call

Make a call to the selected contact.

Send message

Send an SMS/MMS to a contact you selected from Contacts.

Edit

Modify the contents of a file: name, etc.

Delete

Delete the selected contact.

Copy

Copy the selected contact to phone, SIM card.

Settings

- **Copy all**

Copy all contacts to phone or SIM card.

- **Delete all**

Delete all contacts to phone or SIM card.

- **Display mode**

Select to display contacts in "**SIM**", "**Phone**" or "**Phone and SIM**".

- **Memory status**



View used and available space in phone and SIM card.

7

Messages.....

7.1 Write message

From the Message screen select **OK\New** to create a text/multimedia message.



How to type a message:


You can enter text using normal or predictive text input. To set your desired text input, select **Options\ Input method**.

For normal text input, press a number key, 2-9, repeatedly until the desired character is displayed. If the next letter you want is located on the same key as the present one, wait until the cursor is displayed.

For predictive text input, start entering a word by using the 2-9 keys and press the key once and the word will be modified each time you press a key. As you go on, the word will keep changing.

Example: For “**alcatel**”, press on the following keys:

2_{ABC}, **5**_{JKL}, **2**_{ABC}, **2**_{ABC}, **8**_{TUV}
--> **alcatel**.



To insert a punctuation mark or special character, press **0+** key.

If you want to delete the already typed letters or symbols press **↵** to delete them one by one.

7.2 Read message

From the Message screen select **OK\Inbox** to read the text/multimedia message.

How to read a message:

If a message comes, a notification will be shown in the idle screen. Press **View** to read it or press **Cancel** to keep it unread.

If you want to view all the messages received or sent, select **Messages\Inbox\Outbox\Sent**.

While writing a message, select **Options** to access all the messaging options.

You can save any messages that you often send to Drafts.

7.3 Settings

Text message

- **SIM**

You can set validity period, message type, sent on/off, etc.

- **Memory status**

Show memory used on the phone and SIM card.

- **Text msg.counter**

Record send and receive text messages.

- **Save sent message**

You can set whether to save the message has been sent.

- **Preferred storage**

Set the path to save the message.

MMS

- **Data account**

Select your data account for multimedia messages.


- **Common settings**

You can set the slide timing, validity period, home network; select preferred storage way, and check memory status, etc.

8 FM radio

Your phone is equipped with a radio ⁽¹⁾ functionality. You can use the application as a traditional radio with saved channels. You can listen to it while running other applications.

First, to turn on the radio, select **FM radio** from main menu.



⁽¹⁾ The quality of the radio depends on the coverage of the radio station in that particular area.

Then, search the channel by selecting **OK\Options\Auto search** (when using this function for the first time). Stations will be automatically saved to **Channel list**, and you can select one.



How to choose the existed channel:

a. From the FM radio main screen:

Scroll **up/down** key to change the channel.


b. From the channel list:

Select **Options\Channel list** after entering FM Radio, and choose the channel you like. You can **Play/Delete/Edit** the selected channel.

How to add a new channel:

Select **Options\Channel list\
<Empty>\Edit** after entering **FM
Radio**, and edit the **Channel name**
and **Frequency**, then select **Save**.

Finally, to turn off the radio, please
select "**Options\Turn off**".



Available options:

Turn off

Turn off the FM radio

Channel list

Open the list of saved stations.

Save channel

Save the current tuned station to the "**Channel list**".

Auto search

Start auto search and stations will be automatically saved to "**Channel list**".

Enter frequency


Enter the frequency manually.

9

Camera.....

9.1 Camera

9.1.1 Take a photo, save or delete

The screen acts as the viewfinder. Position the object or landscape in the viewfinder and press  to take the image and the images will be automatically saved. If you don't want it, you may directly delete it.

9.1.2 Settings in framing mode

Before taking the photo, you can adjust a number of settings:

Access video

- Access video recording mode.

My creations

- View the images you have taken.

Camera settings

- Set **Banding**, **Timer**, and the **Night mode**.

Image setting

- You can set image size and quality.

White balance

- Select your preferred filter to capture scenes.

Storage

- You may choose saving location if microSD card is inserted.

Restore default

- Return all settings to default values.

9.1.3 Options available after taking the photo


Once you have taken a photo, you can go to "Images" to view it, send it by Bluetooth or MMS, or set it as a wallpaper or power on/off image.

9.2 Video

9.2.1 Framing mode

When you enter the "**Video**" function through "**Camera\Options\Access video**", you are in Framing mode. Use the mobile screen as a viewfinder and press "**Options**" for the settings of **Quality**, **Night mode**, **Record audio**, **Color mode**, **EV**, **Storage**, to **Access camera** and "**Videos**".

9.2.2 Recording mode

Once you have chosen your settings, you can launch the recording of your video-clip by pressing the  key.



If you receive a call in recording mode, video recording will stop and save automatically.



9.2.3 Further operations after shooting a video

After shooting a video, you can choose to send your video by MMS, Bluetooth or go to "**Tools\Videos**" to view it.

In the list of "**My videos**", press "**Options**" to rename the video, set as power on/off screen, etc.

10 Alarm.....

Your mobile phone has a built-in alarm clock with a snooze feature. You can set up your alarm by selecting **Alarm\OK\Edit** from main menu.



- You can set up your time when you access above Alarm screen, select **Edit** to set the repeat time, snooze intervals, Alert type, and Alarm tone

Repeat

You may select **Once (default)/ Everyday/Days** to your preference.

Snooze

The alarm will repeat at regular intervals.

Mode



You may select the mode of Ringtone: **Ring only, Vibrate only, Vib.** and **ring.**

Tone

You may choose one tone as the alarm ringtone.

11 Tools

When you enter this menu, press **OK** to select your preferences in the following features: **Calculator, Calendar, Notes, My files, Bluetooth, Services.**



11.1 Calculator

Enter a number, select the type of operation and enter the second number, press **Equal** to display the result.

11.2 Calendar

Once you enter this menu, there is a monthly-view calendar for you to check date.

11.3 Notes

You can add text that needs to be recorded.

11.4 My files

You will have access to all audio and visual files stored in phone or Memory card in My files..

11.5 Bluetooth



You can activate/deactivate the bluetooth, check device list, edit phone's name, etc

11.6 Services

Contact your network operator to check service availability.

12 Media

When you enter this menu, press OK to select your preferences in the following features: **Games, Music, Images, Videos.**



12.1 Games

There are **Ninja up, Sky Gift, Danger Dash, Nitro Racing** in this menu.

12.2 Music

You can play the songs you prefer in the list.

12.3 Images



You can select an image or a photo as wallpaper, power on/off screen.

12.4 Videos

When access to this feature, you can play, send, rename, delete and store the video according to your preference.

13 Settings.....

From the main menu, select **Settings\OK** and access the function of your choice in order to customise your telephone.



13.1 Phone settings

To modify the Phone settings, select **Phone setting** and you will see **Time and date**, **Schedule power on/off**, **Language**, **Input method**, **Display**, **Flight mode**, **LCD backlight**.

Time and Date

Allows you to have settings of local city, date and time, including 12/24h format.

You can also set the daylight saving adjustment and activate auto update if needed.

Schedule power on/off

You can set the power on/off time in this function.

Language

Display language for messages. The "**Auto**" option selects the language according to the home network (if available).

Input method

Please see chapter "**Latin input mode**", page 66. In addition to the specific characters table for Cyrillic, Chinese, other data input modes are also available in your telephone. This feature allows you to write short messages and add names with special characters to your contacts.

Display

This function allows you to select phone wallpaper, power on/off display.

Flight mode

Voice calls, Bluetooth and messaging functions are barred. Can be used to increase standby duration. .

LCD backlight

This function allows you to adjust brightness level of LCD display, and set backlight time.

13.2 Sound

With this menu, you can set up the

sound mode from **Normal mode, Silent, Vibration.**

13.3 Call settings

You can activate/deactivate **Auto redial, Call time reminder, Answer mode.**

Auto redial

You can activate or deactivate the automatic callback of your party for calls that do not get through the first time.

Call time reminder

you can set reminder time at Single/Periodic mode.

Answer mode

With this feature, switch on/off to choose if Any key answer or Auto answer.

Other Billing

You can access different items with this option.

Caller ID

Set by network or hide, send number.


Call waiting

Activate/Deactivate the notification of a second incoming call by a beep.

Call divert

Call forwarding

You can activate, cancel or verify the status of the call forwarding to the voicemail or to a specified number. The following configurations are possible:

- **Unconditional:** systematic forwarding of all your calls. The  icon is displayed.

Conditional: if your line is busy, if you don't answer or if you are outside the network range.

Call barringcopy

Outgoing calls

The following configurations are possible:

- **All voice calls**

All outgoing calls are barred.

- **International voice calls**

Outgoing international calls are barred.

- **International voice calls except to home**

Outgoing international calls except those to your country of subscription are barred.

Incoming calls

The following configurations are possible:

- **All voice calls**

All incoming calls are barred.

- **Voice call when roaming**

Incoming calls are barred when you are abroad.

Cancel all

Deactivate all call barring.

Change barring password

Change the original barring password for activating call barring.

Line switching

You can select Line1 ad Line2.

13.4 Assistance

Refer to "Assistance (SOS)", page 25.

13.5 Network

You can access this feature to set and select your preferred network and search mode.

13.5.1 Network selection

Preferred network

- List of networks to which you wish to be connected in order of priority.

Select network

- The choice of network connection is left up to the user.

Search mode

- Network connection can be switched between "**Manual**" and "**Auto**".

13.5.2 GPRS connection ⁽¹⁾

When needed

- GPRS mode active depending on requirements.

Always

- GPRS mode continuously active.

13.5.3 GPRS international roaming

GPRS data services can be used while roaming overseas.

⁽¹⁾ Depending on network availability.

13.6 Connectivity

A set of profile settings for data account, multimedia message and weather.

13.7 Security

You can protect your phone by activating and changing the PIN and password, its initial one is 1234. The feature also allows you to lock your phone by activating the PIN2 of **Fixed dial number**.

SIM

Activate PIN

The SIM card protection code is requested each time the phone is powered on.

Fixed dial number

Allows the phone to be "locked" so that it can only dial certain numbers, or numbers with certain prefixes. To activate this function, PIN2 code is mandatory.

Change PIN

Change PIN code.

Change PIN2

A protection code for certain SIM card features (Billing/Cost/FDN, etc.) will be requested if you attempt to access it, if the code is activated. Select to update it with a new one (between 4 and 8 digits).

Phone

Activate password

It is requested each time the phone is powered on.

Change password

Change phone password, its initial one is 1234.

13.8 Regulatory & Safety

View your phone information, such as **Product model**, **Manufacturer name**, **Manufacturer address**, **IMEI**, **CU Reference**, etc.

13.9 Restore default

Make the phone's settings recover to its default value. End-user data will not be erased. Enter its default password 1234 to confirm to restore and reboot.

14 Making the most of your mobile

Mobile Upgrade

Using Mobile Upgrade tool you can update your phone's software from your PC.

Download Mobile Upgrade from alcatel website (www.alcatel-mobile.com) and install it on your PC. Launch the tool and update your phone by following the step by step instructions (refer to the User Guide provided together with the tool).

Your phone's software will now have the latest software.



All personal information will be permanently lost following the update process.

Supported Operating Systems

Windows XP/Vista/Windows 7.

15 Latin input mode.....

There are two text entry methods that can be used to write messages:

- Normal: this mode allows you to type a text by choosing a letter or a sequence of characters.
- Predictive with the eZi mode: this mode speeds up the writing of your text.

Keypad inputting:

Press **0 +** : to change input methods.

Press **✖**  : to access symbols table

Press **#**  : to enter a space

Safety and use

We recommend that you read this chapter carefully before using your phone. The manufacturer disclaims any liability for damage, which may result as a consequence of improper use or use contrary to the instructions contained herein.

● **TRAFFIC SAFETY:**

Given that studies show that using a mobile phone while driving a vehicle constitutes a real risk, even when the hands-free kit is used (car kit, headset...), drivers are requested to refrain from using their mobile when the vehicle is not parked.

When driving, do not use your phone and headphone to listen to music or to the radio. Using a headphone can be dangerous and forbidden in some areas.

When switched on, your phone emits electromagnetic waves that can interfere with the vehicle's electronic systems such as ABS anti-lock brakes or airbags. To ensure that there is no problem:

- do not place your phone on top of the dashboard or within an airbag deployment area,
- check with your car dealer or the car manufacturer to make sure that the dashboard is adequately shielded from mobile phone RF energy.

● **CONDITIONS OF USE:**

You are advised to switch off the telephone from time to time to optimise its performance. Switch the phone off before boarding an aircraft.

Switch the phone off when you are in health care facilities, except in designated areas. As with many other types of equipment now in regular use, mobile telephones can interfere with other electrical or electronic devices, or equipment using radio frequency.

Switch the phone off when you are near gas or flammable liquids. Strictly obey all signs and instructions posted in a fuel depot, petrol station, or chemical plant, or in any potentially explosive atmosphere.

When the phone is switched on, it should be kept at least 15 cm from any medical device such as a pacemaker, a hearing aid or insulin pump, etc. In particular when using the phone, you should hold it against the ear on the opposite side to the device, if any.

To avoid hearing impairment, pick up the call before holding your phone to your ear. Also move the handset away from your ear while using the “hands-free” mode because the amplified volume might cause hearing damage.

Do not let children use the phone and/or play with the telephone and accessories without supervision.

When replacing the cover please note that your phone may contain substances that could create an allergic reaction.

Always handle your phone with care and keep it in a clean and dust-free place.

Do not allow your phone to be exposed to adverse weather or environmental conditions (moisture, humidity, rain, infiltration of liquids, dust, sea air, etc). The manufacturer's recommended operating temperature range is -10°C to $+55^{\circ}\text{C}$.

At over 55°C the legibility of the phone's display may be impaired, though this is temporary and not serious.

Emergency call numbers may not be reachable on all mobile networks. You should never rely only on your phone for emergency calls.

Do not open, dismantle or attempt to repair your mobile phone yourself.

Do not drop, throw or bend your mobile phone.

Do not use the phone if the glass made screen, is damaged, cracked or broken to avoid any injury.

Do not paint it.

Use only batteries, battery chargers, and accessories which are recommended by TCL Communication Ltd and its affiliates and are compatible with your phone model. TCL Communication Ltd and its affiliates disclaim any liability for damage caused by the use of other chargers or batteries.

Remember to make back-up copies or keep a written record of all important information stored in your phone.

Some people may suffer epileptic seizures or blackouts when exposed to flashing lights, or when playing video games. These seizures or blackouts may occur even if a person never had a previous seizure or blackout. If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult your doctor before playing video games on your phone or enabling a flashing-lights feature on your phone.

Parents should monitor their children's use of video games or other features that incorporate flashing lights on the phones. All persons should discontinue use and consult a doctor if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements, or disorientation. To limit the likelihood of such symptoms, please take the following safety precautions:

- Do not play or use flashing-light features if you are tired or need sleep.
- Take a minimum 15-minute break hourly.
- Play in a room in which all lights are on.
- Play at the farthest distance possible from the screen.
- If your hands, wrists, or arms become tired or sore while playing, stop and rest for several hours before playing again.
- If you continue to have sore hands, wrists, or arms during or after playing, stop the game and see a doctor.

When you play games on your phone, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. Follow the instructions to avoid problems such as tendinitis, carpal tunnel syndrome, or other musculoskeletal disorders.



PROTECT YOUR HEARING

To prevent possible hearing damage, do not listen at high volume levels for long periods. Exercise caution when holding your device near your ear while the loudspeaker is in use.

● **PRIVACY:**

Please note that you must respect the laws and regulations in force in your jurisdiction or other jurisdiction(s) where you will use your mobile phone regarding taking photographs and recording sounds with your mobile telephone. Pursuant to such laws and regulations, it may be strictly forbidden to take photographs and/or to record the voices of other people or any of their personal attributes, and duplicate or distribute them, as this may be considered to be an invasion of privacy. It is the user's sole responsibility to ensure that prior authorisation be obtained, if necessary, in order to record private or confidential conversations or take a photograph of another person; the manufacturer, the seller or vendor of your mobile phone (including the operator) disclaim any liability which may result from the improper use of the mobile phone.

● **BATTERY:**

Following air regulation, the battery of your product is not charged. Please charge it first. Before removing the battery from your phone, please make sure that the phone is switched off.

Observe the following precautions for battery use:

- Do not attempt to open the battery (due to the risk of toxic fumes and burns).
- Do not puncture, disassemble or cause a short-circuit in a battery,

- Do not burn or dispose of a used battery in household rubbish or store it at temperatures above 60°C.

Batteries must be disposed of in accordance with locally applicable environmental regulations. Only use the battery for the purpose for which it was designed. Never use damaged batteries or those not recommended by TCL Communication Ltd and/or its affiliates.



This symbol on your telephone, the battery and the accessories means that these phones must be taken to collection points at the end of their life:

- Municipal waste disposal centres with specific bins for these items of equipment
- Collection bins at points of sale.

They will then be recycled, preventing substances being disposed of in the environment, so that their components can be reused.

In European Union countries:

These collection points are accessible free of charge.

All phones with this sign must be brought to these collection points.

In non European Union jurisdictions:

Items of equipment with this symbol are not to be thrown into ordinary bins if your jurisdiction or your region has suitable recycling and collection facilities; instead they are to be taken to collection points for them to be recycled.

CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

● **CHARGERS**

Mains powered chargers will operate within the temperature range of: 0°C to 40°C.

The chargers designed for your mobile phone meet with the standard for safety of information technology equipment and office equipment use. They are also compliant to the ecodesign directive 2009/125/EC. Due to different applicable electrical specifications, a charger you purchased in one jurisdiction may not work in another jurisdiction. They should be used for this purpose only.

● **RADIO WAVES:**

Proof of compliance with international standards (ICNIRP) or with European Directive 1999/5/EC (R&TTE) is required of all mobile phone models before they can be put on the market. The protection of the health and safety for the user and any other person is an essential requirement of these standards or this directive.

THIS DEVICE MEETS INTERNATIONAL GUIDELINES FOR EXPOSURE TO RADIO WAVES.

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves (radio frequency electromagnetic fields) recommended by international guidelines. The guidelines were developed by an independent scientific organisation (ICNIRP) and include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The radio wave exposure guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit for mobile devices is 2 W/kg.

Tests for SAR are conducted using standard operating positions with the device transmitting at its highest certified power level in all tested frequency bands. The highest SAR values under the ICNIRP guidelines for this device model are:

2008G/2008D:

Maximum SAR for this model and conditions under which it was recorded.		
Head SAR	GSM 900+Bluetooth	0.461 W/kg
Body-worn SAR	GSM 900+Bluetooth	1.140 W/kg

During use, the actual SAR values for this device are usually well below the values stated above. This is because, for purposes of system efficiency and to minimize interference on the network, the operating power of your mobile device is automatically decreased when full power is not needed for the call. The lower the power output of the device, the lower its SAR value.

Body-worn SAR testing has been carried out at a separation distance of 5 mm. To meet RF exposure guidelines during body-worn operation, the device should be positioned at least this distance away from the body. If you are not using an approved accessory ensure that whatever product is used is free of any metal and that it positions the phone the indicated distance away from the body.

Organisations such as the World Health Organisation and the US Food and Drug Administration have stated that if people are concerned and want to reduce their exposure they could use a hands-free device to keep the phone away from the head and body during phone calls, or reduce the amount of time spent on the phone.

For more information you can go to
www.alcatel-mobile.com

Additional information about electromagnetic fields and public health are available on the following site: <http://www.who.int/peh-emf>.

Your telephone is equipped with a built-in antenna. For optimal operation, you should avoid touching it or degrading it.

As mobile devices offer a range of functions, they can be used in positions other than against your ear. In such circumstances the device will be compliant with the guidelines when used with headset or usb data cable. If you are using another accessory ensure that whatever product is used is free of any metal and that it positions the phone at least 5 mm away from the body.

Please note by using the device some of your personal data may be shared with the main device. It is under your own responsibility to protect your own personal data, not to share with it with any unauthorised devices or third party devices connected to yours. For products with Wi-Fi features, only connect to trusted Wi-Fi networks. Also when using your product as a hotspot (where available), use network security. These precautions will help prevent unauthorised access to your device. Your product can store personal information in various locations including a SIM card, memory card, and built-in memory. Be sure to remove or clear all personal information before you recycle, return, or give away your product. Choose your apps and updates carefully, and install from trusted sources only. Some apps can impact your product's performance and/or have access to private information including account details, call data, location details and network resources.

Note that any data shared with TCL Communication Ltd. is stored in accordance with applicable data protection legislation. For these purposes TCL Communication Ltd. implements and maintains appropriate technical and organizational measures to protect all personal data, for example against unauthorised or unlawful processing and accidental loss or destruction of or damage to such personal data whereby the measures shall provide a level of security that is appropriate having regard to

- (i) the technical possibilities available,
- (ii) the costs for implementing the measures,
- (iii) the risks involved with the processing of the personal data, and
- (iv) the sensitivity of the personal data processed.

You can access, review and edit your personal information at any time by logging into your user account, visiting your user profile or by contacting us directly. Should you require us to edit or delete your personal data, we may ask you to provide us with evidence of your identity before we can act on your request.

● LICENCES



eZiText™ and Zi™ are trademarks of Zi Corporation and/or its Affiliates.



microSD Logo is a trademark.



The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by TCL Communication Ltd and its affiliates is under license. Other trademarks and trade names are those of their respective owners.

alcatel 2008 Bluetooth Declaration ID D022118

General information...

- **Internet address:** www.alcatel-mobile.com
- **Hot Line Number:** see "TCL Communication Services" leaflet or go to our Internet site.
- **Manufacturer:** TCL Communication Ltd.
- **Address:** Flat/RM 1910-12A, Block 3, China HongKong City, 33 Canton Road, Tsimshatsui, Kowloon, Hong Kong.
- **Electronic labeling path:** Touch Settings\Regulatory & safety or press * # 0 6 #, you can find more information about labeling.⁽¹⁾

On our Internet site, you will find our FAQ (Frequently Asked Questions) section. You can also contact us by e-mail to ask any questions you may have.

An electronic version of this user guide is available in English and other languages according to availability on our server:

www.alcatel-mobile.com

Your telephone is a transceiver that operates on GSM networks in quad-band with 850/900/1800/1900 MHz.

CE | 588

⁽¹⁾ It depends on countries.

This equipment is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. The entire copy of the Declaration of Conformity for your telephone can be obtained through our website: www.alcatel-mobile.com.

Protection against theft ⁽¹⁾

Your telephone is identified by an IMEI (phone serial number) shown on the packaging label and in the phone's memory. We recommend that you note the number the first time you use your telephone by entering * # 0 6 # and keep it in a safe place. It may be requested by the police or your operator if your telephone is stolen. This number allows your mobile telephone to be blocked preventing a third person from using it, even with a different SIM card.

Disclaimer

There may be certain differences between the user manual description and the phone's operation, depending on the software release of your telephone or specific operator services.

TCL Communication Ltd shall not be held legally responsible for such differences, if any, nor for their potential consequences, which responsibility shall be borne by the operator exclusively.

⁽¹⁾ Contact your network operator for service availability.

Telephone warranty ...

Your phone is warranted against any defect or malfunctioning which may occur in conditions of normal use during the warranty period of twelve (12) months ⁽¹⁾ from the date of purchase as shown on your original invoice.

Batteries ⁽²⁾ and accessories sold with your phone are also warranted against any defect which may occur during the first six (6) months ⁽¹⁾ from the date of purchase as shown on your original invoice.

In case of any defect of your phone which prevents you from normal use thereof, you must immediately inform your vendor and present your phone with your proof of purchase.

⁽¹⁾ The warranty period may vary depending on your country.

⁽²⁾ The life of a rechargeable mobile phone battery in terms of conversation time standby time, and total service life, will depend on the conditions of use and network configuration. Batteries being considered expendable supplies, the specifications state that you should obtain optimal performance for your phone during the first six months after purchase and for approximately 200 more recharges.

If the defect is confirmed, your phone or part thereof will be either replaced or repaired, as appropriate. Repaired Phone and accessories are entitled to a one (1) month warranty for the same defect. Repair or replacement may be carried out using reconditioned components offering equivalent functionality.

This warranty covers the cost of parts and labor but excludes any other costs.

This warranty shall not apply to defects to your phone and/or accessory due to (without any limitation):

- 1) Non-compliance with the instructions for use or installation, or with technical and safety standards applicable in the geographical area where your phone is used,
- 2) Connection to any equipment not supplied or not recommended by TCL Communication Ltd,
- 3) Modification or repair performed by individuals not authorised by TCL Communication Ltd or its affiliates or your vendor,
- 4) Modification, adjustment or alteration of software or hardware performed by individuals not authorised by TCL Communication Ltd,

5) Inclement weather, lightning, fire, humidity, infiltration of liquids or foods, chemical phones, download of files, crash, high voltage, corrosion, oxidation...

Your phone will not be repaired in case labels or serial numbers (IMEI) have been removed or altered.


There are no express warranties, whether written, oral or implied, other than this printed limited warranty or the mandatory warranty provided by your country or jurisdiction.

In no event shall TCL Communication Ltd or any of its affiliates be liable for indirect, incidental or consequential damages of any nature whatsoever, including but not limited commercial or financial loss or damage, loss of data or loss of image to the full extent those damages can be disclaimed by law.

Some countries/states do not allow the exclusion or limitation of indirect, incidental or consequential damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you.

Troubleshooting

Before contacting the service centre, you are advised to follow the instructions below:

- You are advised to fully charge () the battery for optimal operation.
- Avoid storing large amounts of data in your phone as this may affect its performance.
- Use User Data Format and the Mobile Upgrade tool to perform phone formatting or software upgrading, ALL User phone data: contacts, photos, messages and files will be lost permanently.

and carry out the following checks:

My phone is frozen or can't switch on

- Check the battery contacts, remove and reinstall your battery, then turn your phone on
- Check the battery power level, charge for at least 20 minutes
- If it still does not work, please use User Data Format to reset the phone or Mobile Upgrade to upgrade software

My phone has not responded for several minutes

- Restart your phone by pressing and holding the  key

- Remove the battery and re-insert it, then restart the phone
- If it still does not work, please use User Data Format to reset the phone or Mobile Upgrade to upgrade software

My phone turns off by itself

- Check whether your phone is locked when not in use, and make sure you don't accidentally turn off your phone when locking it by pressing the power key
- Check the battery charge level
- If it still does not work, please use User Data Format to reset the phone or Mobile Upgrade to upgrade software

My phone can't charge properly

- Make sure you are using an alcatel battery and the charger from the box
- Make sure your battery is inserted properly and clean the battery contact if it's dirty. It must be inserted before plugging in the charger
- Make sure that your battery is not completely discharged; if the battery power is empty for a long time, it may take around 20 minutes to display the battery charger indicator on the screen.
- Make sure charging is carried out under normal conditions (0°C to +40°C)
- When abroad, check that the voltage input is compatible

My phone can't connect to a network or "No service" is displayed

- Try connecting in another location
- Verify the network coverage with your operator
- Check with your operator that your SIM card is valid
- Try selecting the available network(s) manually
- Try connecting at a later time if the network is overloaded

Invalid SIM card

- Make sure the SIM card has been correctly inserted
- Make sure the chip on your SIM card is not damaged or scratched
- Make sure the service of your SIM card is available

Unable to make outgoing calls

- Make sure you have dialed a valid number and press the send key
- For international calls, check the country and area codes
- Make sure your phone is connected to a network, and the network is not overloaded or unavailable
- Check your subscription status with your operator (credit, SIM card valid, etc.)

- Make sure you have not barred outgoing calls
- Make sure that your phone is not in flight mode

Unable to receive incoming calls

- Make sure your phone is switched on and connected to a network (check for overloaded or unavailable network)
- Check your subscription status with your operator (credit, SIM card valid, etc.)
- Make sure you have not forwarded incoming calls
- Make sure that you have not barred certain calls
- Make sure that your phone is not in flight mode


The caller's name/number does not appear when a call is received

- Check that you have subscribed to this service with your operator
- Your caller has concealed his/her name or number

I can't find my contacts

- Make sure your SIM card is not broken
- Make sure your SIM card is inserted properly
- Import all contacts stored in SIM card to phone

The sound quality of the calls is poor

- You can adjust the volume during a call by pressing the navigation key
- Check the network strength 
- Make sure that the receiver, connector or speaker on your phone is clean

I am unable to use the features described in the manual

- Check with your operator to make sure that your subscription includes this service
- Make sure this feature does not require an alcatel accessory

When I select a number from my contacts, the number can't be dialed

- Make sure that you have correctly recorded the number in your file
- Make sure that you have selected the country prefix when calling a foreign country

I am unable to add a contact in my contacts

- Make sure that your SIM card contacts are not full; delete some files or save the files in the phone contacts

My callers are unable to leave messages on my voicemail

- Contact your network operator to check service availability

I can't access my voicemail

- Make sure your operator's voicemail number is correctly entered in "**Messages\ Voicemail**"
- Try later if the network is busy

The flickering icon is displayed on my standby screen

- You have saved too many short messages on your SIM card; delete some of them or archive them in the phone memory

SIM card PIN locked

- Contact your network operator to obtain the PUK code (Personal Unblocking Key)

How to make your battery last longer

- Make sure you follow the complete charge time (minimum 3 hours)
- After a partial charge, the battery level indicator may not be exact. Wait for at least 20 minutes after removing the charger to obtain an exact indication
- Switch on the backlight upon request

I am unable to send and receive MMS

- Check your phone memory availability as it might be full
- Contact your network operator to check service availability and check MMS parameters

- Verify the server centre number or your MMS profile with your operator
- The server centre may be swamped, try again later

The phone can't be detected by others via Bluetooth

- Make sure that Bluetooth is turned on and your phone is visible to other users
- Make sure that the two phones are within Bluetooth's detection range

alcatel is a trademark of
Alcatel-Lucent and is
used under license by TCL
Communication Ltd

All rights reserved
© Copyright 2016
TCL Communication Ltd

TCL Communication Ltd reserves
the right to alter material
or technical specification
without prior notice.