

FAT GECKO[®]

Kaboom Quick Start Guide

Product Contents

Tube A: 10" Carbon Fiber with Ball Head



Tube B: 10" Carbon Fiber



Tube C: 10" Carbon Fiber with Handle



Tube D & E: 15" Carbon Fiber (2)



Adhesive Mount (2)



1/4"-20 Mount (2)



Clip with Nut & Bolt

Clamp with Nut & Bolt



Clip

Clamp

Helmet Mount



1. Attach **Tube A** and **Tube B** together
2. Attach (1) **Adhesive Mount** to **Tube A** using the **Clip** with a **Nut & Bolt**
3. Attach (1) **Adhesive Mount** to **Tube B** using the **Clamp** with a **Nut & Bolt**
4. Determine the angle & position of the **Kaboom** on your helmet
5. Remove the backing from the **Adhesive Mounts** and apply pressure to attach them to your helmet
6. Tighten the **Bolts** on the **Clip & Clamp** to lock the angle into place
7. Adjust the **Ball Head** to achieve your desired shot

Vehicle Mount



1. Attach **Tube A** and **Tube B** together
2. Attach the 1/4"-20 **Mounts** to each of your **Fat Gecko Suction Mounts**.
3. Attach (1) 1/4"-20 **Mount** to **Tube A** using the **Clip** with a **Nut & Bolt**
4. Attach (1) 1/4"-20 **Mount** to **Tube B** using the **Clamp** with a **Nut & Bolt**
5. Determine the angle & position of the **Kaboom** on your vehicle
6. Attach the **Fat Gecko Suction Mounts** to your vehicle.
7. Tighten the **Bolts** on the **Clip & Clamp** to lock the angle into place
8. Adjust the **Ball Head** to achieve your desired shot

DELKIN DEVICES[®]

www.delkin.com | 800.637.8087 | 858.391.1234

FAT GECKO[®]

Kaboom Quick Start Guide

High-Angle



Optional Accessories: Fat Gecko Smart Phone Bracket

1. Use any combination of Tubes A, B, C, D or E (based on your desired height) and attach them together

Note: Height can range from 20" - 60" (50.8 - 152.4 cm.)

Self-Portrait



1. Use any combination of Tubes A, B, C, D or E (based on your desired length) and attach them together

Note: For the best results, use Tubes A, B & C

Tripod Extender



Optional Accessories: Fat Gecko Smart Phone Bracket

1. Use any combination of Tubes A, B, C, D or E (based on your desired height) and attach them together
2. Attach the Kaboom to a tripod using the female 1/4"-20 thread that is built into the bottom of the rubber-padded handle.

DELKIN DEVICES[®]

www.delkin.com | 800.637.8087 | 858.391.1234